BILL'S HOME TECH

Home & Small Business Tech Solutions

AN EXTENDED GUIDE · NO. 2135

Updated November 2026

Free Up Space on a Reading/Video Tablet

Clear room on a Kindle, Fire, or iPad used for books and shows — without losing your library

Plain-English tech help from:
Bill's Home Tech
Portage County, Ohio

Tech Made Simple. Service Made Personal.

Bill Davis — Bill's Home Tech
(330) 200-8042 · bill@billshometech.com · Atwater, Ohio

Book a visit · billshometech.com/book

What's Inside

Everything in this guide, with page numbers. Skip to whichever chapter answers your question right now.

The 60-Second Version 3

The Short Version 3

Why These Tablets Fill Up 4

See What's Using the Space 4

Remove Downloaded Books and Magazines 5

Delete Downloaded Movies and Shows 6

Clear App Clutter and Caches 6

Kindle E-Readers: A Special Note 7

Audiobooks and Podcasts: Quiet Hogs 7

Photos on a Tablet 8

Your Library Is Safe in the Cloud 9

When the Tablet Is Just Old 9

Keep the Tablet Lean 10

What Not to Remove 10

When to Call Bill 11

Everyday Cheat Sheet 12

A Note From Bill 13

Your Visit — and My Promise 14

SUMMARY

The 60-Second Version

A reading or video tablet fills up with downloaded books, shows, movies, and apps — but your library lives safely in the cloud, so clearing the tablet never loses it. Check the storage screen (Fire: Settings, Storage; iPad: General, iPad Storage) to find the culprit, usually downloaded video. Delete watched movies and shows from each video app's Downloads (the biggest win), and "Remove from Device" finished books (never "Delete from library").

Clear app caches (not data) and uninstall unused games. A true Kindle rarely fills up because books are tiny. Keep it lean by deleting each show right after you watch it.

1 The Short Version

Reading and video tablets fill up with downloaded content — books, magazines, movies, and shows you saved to enjoy offline — plus the apps themselves. The key comfort is that almost all of it lives safely in your account in the cloud; what is on the tablet is just a downloaded copy you can remove and re-download any time.

So freeing space here is low-stress: you are clearing copies, not originals. We will go through the safe cleanups for Kindles, Fire tablets, and iPads, and finish with how to keep the tablet from filling up again.

- Your books and shows live in the cloud — clearing the tablet does not lose them.
- Downloaded books, movies, and shows are the usual space users.
- Removing a download keeps it in your library to re-download later.
- A few habits keep a reading or video tablet comfortably lean.

TIP

The golden rule for these tablets: removing a downloaded book or show from the device does not delete it from your account. It drops back into your library as a cloud item you can download again in seconds, so you can clear freely without losing anything.

2 Why These Tablets Fill Up

A reading or video tablet is built around downloading content to enjoy without internet — which is wonderful on a plane or a porch, but means things quietly accumulate. Every book you open, every show you save for a trip, and every magazine issue stays downloaded until you remove it.

Video is the heavyweight by far. A single downloaded movie can take more room than hundreds of books, so a few saved films or TV episodes are often the real reason a tablet is suddenly full. Books, by contrast, are tiny.

GOOD TO KNOW

This is why a Kindle used only for reading rarely fills up — books are small — while a Fire tablet or iPad used for movies fills fast. If your tablet is tight on space, downloaded video is the first place to look.

3 See What's Using the Space

Each tablet shows where its storage went, which points you at the real culprit before you remove anything.

1. Fire tablet: Settings, then "Storage" (or "Device Options," then Storage) — it breaks down by apps, video, books, and photos.
2. iPad: Settings, General, iPad Storage — sorted biggest first, with safe recommendations at the top.

3. Kindle (e-reader): the simple menu shows storage under Settings; books take little, so it is rarely tight.
4. Note the biggest category — usually video or apps — and start there.

> **TIP**
> On a Fire tablet or iPad, the storage screen sorts everything biggest first, so the top of the list is where your space went. Start there and you will reclaim the most room with the least effort.

4 Remove Downloaded Books and Magazines

Books and magazines you have finished can be removed from the tablet while staying in your library forever. On a Kindle or the Kindle app, this is called removing from device.

1. Press and hold a book's cover (or tap the three dots beside it).
2. Choose "Remove from Device" (not "Delete" — remove keeps it in your library).
3. The book drops back to the cloud, shown with a little download arrow to get it again.
4. Repeat for finished books and old magazine issues, which can be surprisingly large.

> **WATCH OUT**
> Choose "Remove from Device," not "Delete permanently" or "Delete from library." Removing frees the tablet while keeping the book in your account; deleting from the library can remove your access to it entirely. When in doubt, "remove from device" is always the safe choice.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

5 Delete Downloaded Movies and Shows

This is where the real space is. Movies and TV episodes downloaded for offline viewing are large, and deleting the ones you have watched frees the most room by far — and they stay in your streaming library to download again.

1. Open the video app (Prime Video, Netflix, Disney+, and so on).
2. Find its "Downloads" section.
3. Delete episodes and films you have finished watching.
4. The titles remain available to stream or re-download whenever you like.

GOOD TO KNOW

A single downloaded movie can take a few gigabytes, so clearing even a handful of watched films often frees more space than all your books combined. If your tablet is full, start here.

6 Clear App Clutter and Caches

The apps themselves, and the temporary files they build up, take room too. Clearing caches is safe and does not log you out, and removing apps you no longer use frees more.

1. Fire tablet: Settings, Apps, pick an app, and use "Clear Cache" (safe), or uninstall apps you do not use.
2. iPad: offload unused apps in Settings, General, iPad Storage (keeps your data), or delete ones you do not need.
3. Remove games the grandchildren installed and nobody plays — games can be large.
4. Leave the reading and video apps you actually use.

WATCH OUT

On a Fire tablet, use "Clear Cache," not "Clear Data" — cache is the safe scratch pad, while clearing data can log you out and remove your downloads and settings. Stick to cache unless you mean to reset an app.

7 Kindle E-Readers: A Special Note

A true Kindle e-reader — the simple black-and-white reading device — almost never runs out of space, because books are tiny and it does not play video. If yours is full, it is usually from a large number of downloaded books, personal documents, or audiobooks.

- Remove from device any books you have finished — they stay in your library.
- Audiobooks are far larger than books; remove listened-to ones if your Kindle plays them.
- Remove personal documents you sent to the Kindle once you are done with them.
- A restart (hold the power button) clears minor glitches and recounts space.

> **GOOD TO KNOW**
>
> Because e-reader books are so small, a Kindle that claims to be full is unusual — if it persists after removing books and audiobooks, a simple restart often sorts it, and if not, it is worth a closer look.

8 Audiobooks and Podcasts: Quiet Hogs

Sound takes more room than people expect. A single audiobook can be larger than a shelf of regular books, and podcast apps quietly hoard every episode you download. On a tablet used for listening as well as reading, these are often the real reason it is full.

1. In your audiobook app (Audible, Libby, and so on), remove titles you have finished listening to — they stay in your library.
2. In podcast apps, delete played episodes, and set them to auto-delete after playing if the option exists.
3. Check for downloaded music albums you no longer need offline.
4. A finished audiobook removed from the device re-downloads any time you want it again.

GOOD TO KNOW

Podcast apps are the sneakiest, because they often download new episodes automatically and never delete the old ones. Turning on "delete after playing" is a one-time setting that quietly stops them filling the tablet.

9 Photos on a Tablet

Many people use a tablet to view photos too, and a large photo collection can take real space — especially if the tablet also takes pictures. The same safe approach that works on a phone works here: let the cloud hold the originals.

- iPad: turn on iCloud Photos with "Optimize iPad Storage" so originals live in iCloud.
- Fire tablet: use the Amazon Photos app or Google Photos to back up and then free local copies.
- Delete obvious junk — screenshots, duplicates, blurry shots — as on any device.
- Empty the photo app's trash to actually reclaim the space.

TIP

If you mostly use the tablet to look at photos rather than take them, you may not need the full library stored on it at all — viewing them from the cloud when you want them keeps the tablet light.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

10 Your Library Is Safe in the Cloud

It is worth repeating, because it is the whole reason you can clear freely: everything you have bought or borrowed lives in your account, not just on the tablet. Amazon keeps your books, your streaming services keep your shows, and all of it is waiting to re-download.

That means the tablet is really just a window onto a much larger library stored safely online. Removing a download closes that window for one item; opening it again is a tap and a short wait. Nothing you paid for is ever at risk from clearing the device.

> *The tablet is just a window onto your cloud library. Clearing a download never closes the library — only that one window, which reopens with a tap.*

11 When the Tablet Is Just Old

Sometimes the real issue is not space at all but age. Reading and video tablets, especially inexpensive ones, have a comfortable life of several years, after which they slow down, struggle to run the latest apps, or stop getting updates. It is worth recognizing this so you do not keep clearing space on a tablet whose trouble is really its age.

A tablet that is slow even when nearly empty, that cannot update its apps, or that no longer receives system updates has usually reached that point. The good news is that these tablets are inexpensive to replace, and because your whole library lives in the cloud, a new one simply signs in and your books and shows are all there.

- Slow even when nearly empty points to age, not storage.
- Apps that will no longer install or update are a sign the tablet is behind.
- Your library moves to a new tablet instantly — just sign in.

- These tablets are cheap to replace compared with a phone or computer.

> **WATCH OUT**
> If you are not sure whether your tablet is worth keeping or has simply aged out, I can tell you honestly — and if a new one makes sense, I will make sure your books, shows, and account move across so nothing is lost. There is no point clearing space on a device whose real problem is its years.

12 Keep the Tablet Lean

A few habits keep a reading or video tablet from filling up again, so you are not clearing it every month.

- Delete downloaded movies and shows as soon as you have watched them.
- Remove finished books from the device now and then (they stay in your library).
- Turn off any "download automatically" setting in your video apps.
- Uninstall games and apps nobody uses, especially ones added by visitors.
- Restart the tablet occasionally to clear temporary files.

> **TIP**
> The one habit that matters most is deleting a movie or show the moment you finish it. Video is the heavyweight, so clearing watched video right away keeps the tablet comfortable with almost no effort.

13 What Not to Remove

Clearing a reading or video tablet is low-risk, but a couple of choices are worth getting right so you keep access to everything you have paid for. The safe moves all share a theme: remove the downloaded copy, never the library entry.

- Do not choose "Delete from Library" or "Return" for books you own — use "Remove from Device."
- Do not cancel or delete the account the library is tied to while clearing space.

- Do not uninstall the main reading or video app if it holds your only way to reach the library — reinstalling is fine, but know your login.
- Do not delete personal documents you sent to the tablet unless you have another copy.

> **WATCH OUT**
> The one genuinely risky option on these tablets is anything that removes a title from your library or returns a borrowed book, rather than just removing the download. When the wording mentions your "library," "account," or "returning" a title, slow down — "remove from device" is the one you want.

14 When to Call Bill

Most people can free plenty of room on a reading or video tablet with the steps here, and because the library is safe in the cloud, it is low-risk. But if the tablet stays full after clearing downloads, if you are nervous about which "remove" or "delete" option is safe, or if a Fire tablet or iPad is behaving oddly, there is no need to wrestle with it.

I come to you, clear the tablet safely without touching your library, set the video apps so downloads do not pile back up, and make sure your books and shows are all still there and easy to get. You end up with a lean tablet and your whole library intact.

- The tablet stays full even after you clear downloads.
- You are unsure which "remove" or "delete" option is safe.
- A Fire tablet or iPad is slow or behaving oddly.
- You want the download settings tidied so it stays lean.

CHEAT SHEET

Everyday Cheat Sheet

Keep this handy. Your library is safe in the cloud — clear freely.

I want to...	Do this...
See where space went	Fire: Settings Storage; iPad: General iPad Storage
Free the most room	Delete watched movies and shows from the video app's Downloads
Clear finished books	Press and hold "Remove from Device" (not Delete)
Tidy apps safely	"Clear Cache" (not Data); uninstall unused games
Kindle is full (rare)	Remove finished books and audiobooks; restart
Keep it lean	Delete each show as soon as you've watched it
Get help	Call Bill: (330) 200-8042

BEFORE YOU GO

A Note From Bill

A quick note from Bill. I write these guides to make home tech a little less frustrating, and I do my best to keep every step accurate and up to date. Still, every home, device, and setup is a bit different, so I can't promise a guide will match yours exactly or fix your particular problem. These guides are for general information only — they're not professional, legal, or financial advice, and they don't replace your device's own manual or the manufacturer's instructions. Please go slow, use your own good judgment, and use everything here at your own risk. If a step involves electrical wiring, a gas appliance, a water heater, plumbing, or climbing a ladder — or if anything just doesn't feel safe — please stop and call a licensed professional (or give me a call at 330-200-8042). Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results.

HOW I CAN HELP

Your Visit — and My Promise

You don't have to remember all of it — just that a friendly, patient person is one call away, whenever you'd rather have a hand.

KEY SPECS

In your home — $99 flat for the first visit, no contracts and no surprises, with a 30-day come-back-free follow-up. In-home visits cover Portage County, Ohio and nearby communities.
Outside the area? Remotely — $49 for a screen-share session (free for Support Plan members, $39/mo), refundable if I can't fix it — and credited toward a visit if you'd rather have me in person. Book either at billshometech.com/book.

GOOD TO KNOW

My promise — If you're not 100% satisfied with your visit, I'll come back at no charge, or refund the full $99. No questions, no awkwardness. That's how I'd want to be treated.

Whenever you're ready, I'll come to your home anywhere in Portage County, Ohio and nearby communities, at your pace. Too far for a house call? I also help remotely. Book at billshometech.com/book or call (330) 200-8042. — Bill

Call or text (330) 200-8042 · bill@billshometech.com

This free guide is for general information only — not professional advice, and no substitute for your device's own manual. Any prices or outside products mentioned can change; please confirm current details before you buy. Please use your own good judgment and follow it at your own risk — for anything involving electricity, gas, water, or heights, stop and call a licensed professional. Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results. © 2026 Bill's Home Tech, LLC.