BILL'S HOME TECH

Home & Small Business Tech Solutions

AN EXTENDED GUIDE · NO. 2163

Updated November 2026

It Prints Blank Pages — Ink vs. Clogged Heads

Why a page comes out blank, and how to tell a dried-up print head from an empty cartridge

Plain-English printer help from:

Bill's Home Tech

Portage County, Ohio

Tech Made Simple. Service Made Personal.

Bill Davis — Bill's Home Tech

(330) 200-8042 · bill@billshometech.com · Atwater, Ohio

Book a visit · billshometech.com/book

What's Inside

Everything in this guide, with page numbers. Skip to whichever chapter answers your question right now.

The 60-Second Version 3

The Short Version 3

What a Blank Page Is Really Telling You 4

First, Rule Out the Simple Things 4

Check Your Ink or Toner Levels 5

Run a Nozzle Check or Test Page 6

Clean the Print Heads (Inkjet) 6

The Soak Method for a Stubborn Clog 7

Blank Pages on a Laser Printer 8

Reseat and Reset the Cartridges 8

Check the Paper and Tray Settings 9

Print From Your Phone as a Cross-Check 9

Stop It Happening Again 10

When One Color Is Missing but Not All 10

A Word on Refilled and Off-Brand Cartridges 11

When to Call Bill 11

Everyday Cheat Sheet 13

A Note From Bill 14

Your Visit — and My Promise 15

SUMMARY

The 60-Second Version

A blank page means ink or toner is not reaching the paper, not that the printer is broken. On an inkjet, the usual cause is a dried, clogged print head from sitting idle — run a nozzle check, then a cleaning cycle or two, and compare the patterns. On a laser, check the orange sealing tape is off and the toner cartridge is seated.

Rule out simple things first: packing tape on new cartridges, an empty tank, or a wrong-tray setting. Printing a page every couple of weeks keeps an inkjet from drying up in the first place.

1 The Short Version

A blank page is the printer's way of telling you that ink or toner is not reaching the paper. On an inkjet printer — the common home kind that uses liquid ink — the usual reason is a dried-up print head that has clogged from sitting unused. On a laser printer, which uses powder toner, a blank page points instead at the toner cartridge or a bit of protective tape. The good news is that you rarely have a broken printer; you have a printer asking for a little maintenance.

- Blank pages mean ink or toner is not getting to the paper — not that the printer is dead.
- Inkjet: the most common cause is a clogged print head from sitting idle; a cleaning cycle usually fixes it.
- Laser: check the toner cartridge is seated and that all orange packing tape was removed.
- Run the printer's own “test page” or “nozzle check” first — it tells you exactly what is missing.

TIP

Before anything fancy, check you did not accidentally send a blank page or print white text on a white background. Print something you know is full of black text, like a web page, as your test — it rules out the document itself in one step.

2 What a Blank Page Is Really Telling You

Printers lay down an image in one of two ways. An inkjet sprays tiny droplets of liquid ink through a row of microscopic nozzles called the print head. A laser printer melts fine plastic powder, the toner, onto the page with heat. When the page comes out blank, something in that chain has stopped — the nozzles are blocked, the ink or toner is gone, or a protective cover is still in place.

Knowing which kind of printer you have narrows the search immediately. If your printer uses cartridges of liquid ink and you buy “ink,” it is an inkjet. If it uses a larger cartridge of powder and you buy “toner,” it is a laser. The fixes are quite different, so it is worth being sure which you have before you start.

GOOD TO KNOW

Inkjets that sit unused for a few weeks are the number-one source of blank pages. The liquid ink dries in the nozzles like paint left with the cap off. This is normal, not a defect — and it is exactly why printing a page every week or two keeps a printer healthy.

3 First, Rule Out the Simple Things

Before you run any cleaning, spend two minutes ruling out the causes that need no ink at all. These catch a surprising number of “blank page” calls.

1. Check you are printing the right thing — open a normal web page or email and print that as a test.

2. On a brand-new cartridge, pull off every strip of plastic film or orange tape; a covered nozzle or vent prints nothing.
3. Make sure the cartridge clicked fully into place; a loosely seated cartridge will not touch the paper.
4. Confirm you are not in a special mode — some printers have a “no ink” or “forms” setting that prints only outlines.

WATCH OUT

New cartridges often have a clear protective tape over the print nozzles and a tiny colored tab over an air vent. Both must come off. If a new cartridge prints blank, a missed strip of tape is the first thing to check — before you decide the cartridge is faulty.

4 Check Your Ink or Toner Levels

It sounds obvious, but a cartridge can run dry gradually until one color, or all of it, simply stops. Most printers can show you an estimated level on their own screen or through the maker's app on your phone.

1. On the printer's screen, look for an ink-drop or toner icon, often under a “Setup” or “Tools” menu.
2. Or open the maker's app — HP Smart, Canon PRINT, Epson Smart Panel, or Brother Mobile Connect — which shows levels at a glance.
3. If one color reads empty or very low, that explains a blank or wrong-colored page; replace that cartridge.
4. If levels look fine but the page is still blank, the problem is a clog, not an empty tank — move to the cleaning steps.

GOOD TO KNOW

Ink-level readings are estimates, not fuel gauges. A cartridge marked “low” often has plenty left, and one marked “full” can still be clogged. Treat the number as a clue, not a verdict — the nozzle-check page in the next chapter tells the real story.

5 Run a Nozzle Check or Test Page

Nearly every inkjet can print a diagnostic pattern — usually called a “nozzle check” — that shows a block or grid of lines for each color. It is the single most useful thing you can do, because it shows you exactly which colors are getting through and which nozzles are blocked.

1. From the printer's menu, find Setup or Maintenance, then “Nozzle Check” or “Print Quality”; print the pattern.
2. Look at the result: solid, complete blocks of each color mean clear nozzles.
3. Gaps, missing lines, or whole missing colors mean clogged nozzles that a cleaning can usually clear.
4. A totally blank nozzle-check page points to an empty cartridge, a cartridge not seated, or tape still in place.

> **TIP**
>
> Keep the nozzle-check page. After you run a cleaning, print a fresh one and compare the two side by side — that is how you know whether the cleaning actually helped or whether you need to run it again.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

6 Clean the Print Heads (Inkjet)

If the nozzle check showed gaps, a built-in cleaning cycle flushes the nozzles with a little ink to clear the dried blockage. It is safe and designed for exactly this, though it does use some ink, so run it a step at a time rather than over and over.

1. From the printer's Maintenance menu (or the maker's app), choose “Clean Print Head” or “Head Cleaning.”
2. Let it run — it takes a minute or two and may sound busier than usual.
3. Print a fresh nozzle check and compare it with the first one.
4. If it improved but is not perfect, run one more cleaning; if it is unchanged after two or three, stop and let it rest.

> **WATCH OUT**
>
> Running cleaning cycle after cycle wastes a lot of ink and rarely helps once the first few have not. If two or three cleanings do not clear it, the clog is stubborn and needs the soak method in the next chapter — or a fresh cartridge — rather than more cleanings.

7 The Soak Method for a Stubborn Clog

When cleanings will not clear a dried head, a gentle soak often revives it. On many home printers the print head is built into the cartridge itself, so you are really reviving the cartridge; on others the head is a separate part in the printer. Either way the idea is the same: warm water dissolves the dried ink.

1. Remove the cartridge and look at the underside for the small metal or gold nozzle strip.
2. Dampen a folded paper towel with warm (not hot) water and rest the nozzle strip on it for a few minutes.
3. You should see a faint smear of ink bleed onto the towel — that means the nozzles are opening up.
4. Blot gently, let it dry, reinstall, and run a nozzle check.

> **WATCH OUT**
>
> This trick works often but not always, and a truly dried-out cartridge may simply be past saving. If you would rather not fuss with wet cartridges — or the printer has a separate, expensive print head you do not want to risk — that is a fine moment to let me take a look rather than gamble on it.

8 Blank Pages on a Laser Printer

Laser printers almost never clog, so a blank page from a laser has different causes. The most common are a toner cartridge with its sealing tape still in place, a cartridge that has genuinely run out, or a cartridge that is not seated properly.

- New toner cartridge: pull out the long orange or clear sealing strip completely before installing.
- Gently rock the cartridge side to side before inserting to redistribute toner that has settled.
- Reseat the cartridge firmly until it clicks — a slightly loose one prints nothing.
- If the page is blank with a faint ghost of text, the cartridge is nearly empty or the imaging drum is worn.

> **GOOD TO KNOW**
>
> Laser toner can settle to one side if the printer has sat unused, giving blank or patchy pages. Taking the cartridge out and rocking it gently end to end a few times often brings a “dead” cartridge back for dozens more pages.

9 Reseat and Reset the Cartridges

Sometimes the printer and cartridge simply lose their handshake — the printer cannot “see” the ink even though it is there. Taking the cartridges out and putting them back often re-establishes that contact.

1. Turn the printer on and open the cartridge door so the carriage moves to the center.
2. Lift out each cartridge, check the gold contacts are clean, and wipe them gently with a dry lint-free cloth if needed.
3. Click each cartridge firmly back into place.
4. Close the door, let the printer settle, and print a test page.

WATCH OUT

If a cartridge's metal contacts look smudged with ink, a soft dry cloth or a clean pencil eraser used gently can restore the connection. Never use a wet cloth on the electrical contacts — only on the nozzle strip in the soak method.

10 Check the Paper and Tray Settings

Occasionally the page is not really blank — the printer pulled from the wrong tray, printed on the back of pre-printed paper, or shrank the image to a corner. A couple of checks rule this out.

- Confirm the paper is loaded print-side as the tray marking shows.
- Check you did not select a huge paper size that pushed the content off the page.
- Make sure the right tray is selected if your printer has more than one.
- Try a single sheet of plain white copier paper to rule out unusual paper.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

11 Print From Your Phone as a Cross-Check

Printing the same thing from your phone is a quick way to tell whether the problem is the printer itself or the computer and its software. If the phone prints blank too, the printer needs the ink or head fixes above; if the phone prints fine, the computer's settings are the culprit.

1. Put your phone on the same Wi-Fi as the printer.
2. Open a photo or web page, tap Share or the menu, and choose Print.
3. Pick your printer and print a test.

4. Compare: blank from phone too means a printer-side ink or head issue; fine from phone means a computer setting.

12 Stop It Happening Again

Most blank-page trouble on inkjets comes from letting the printer sit idle too long. A little routine keeps the nozzles wet and the printer happy, and costs almost nothing.

- Print at least one page — even a test page — every week or two to keep ink flowing.
- Leave the printer powered on or let it sleep rather than unplugging it; most run a quiet self-maintenance cycle.
- Store spare cartridges sealed, upright, and away from heat until you need them.
- If you rarely print, consider a laser printer, which does not clog and can sit for months.

> **GOOD TO KNOW**
>
> If you print only a few times a year, an inkjet will fight you with clogs every time. A small black-and-white laser printer is often the calmer choice for occasional printing — something worth weighing when your current one finally gives up.

13 When One Color Is Missing but Not All

Sometimes the page is not fully blank — it comes out missing just one color, so photos look oddly tinted or black text prints with a greenish or pinkish cast. That points to one clogged or empty color rather than a whole-printer problem, and it narrows the fix nicely.

1. Run a nozzle check and see which color's block is faint or missing.
2. Check that color's level in the maker's app; replace it if it reads empty.
3. If the level is fine, run one head cleaning aimed at clearing that color.
4. Re-run the nozzle check to confirm the missing color has returned.

GOOD TO KNOW

On most home inkjets you cannot print in black alone if a color cartridge is empty — the printer insists all cartridges be usable even for a black-and-white page. That surprises people, but it is normal, not a fault. A single empty color can stop the whole page.

14 A Word on Refilled and Off-Brand Cartridges

If the blank pages started right after you fitted a cheaper third-party or refilled cartridge, the cartridge itself may be the cause. Off-brand cartridges vary in quality, and some do not seat or feed ink as reliably as the maker's own.

- Try reseating the cartridge firmly; off-brand ones sometimes sit slightly loose.
- If you kept the original cartridge, pop it back in to see whether the page prints.
- A refilled cartridge that prints blank may simply have dried out or not been refilled fully.
- Weigh the savings against the hassle — constant clogs can cost more in wasted paper and time.

WATCH OUT

A new third-party cartridge that prints blank from the start is often the cartridge, not the printer. Before you run cleaning after cleaning, test with a known-good or genuine cartridge to be sure you are not chasing a ghost.

15 When to Call Bill

Clearing a blank-page printer is usually a matter of a nozzle check, a cleaning, and perhaps a fresh cartridge — and most people get there on their own with this guide. But dried-up heads can be stubborn, and there is no sense pouring money into cartridges if the real trouble is a failing print head or an aging printer.

If the cleanings and the soak have not brought it back, if you are not sure whether to keep spending on ink, or if you would simply rather have it sorted and tested in one visit, that is exactly what I do. I will get it printing cleanly, tell you honestly whether it is worth keeping, and leave you with a simple routine so it does not dry up again.

- Cleanings and a cartridge change have not cleared the blank pages.
- You are unsure whether to keep buying ink or replace the printer.
- The print head is a separate, costly part you do not want to risk.
- You would rather have it fixed, tested, and explained in one visit.

CHEAT SHEET

Everyday Cheat Sheet

Keep this by the printer. Work down the list; stop as soon as it prints.

I want to…	Do this…
See what's really missing	Print a “nozzle check” from the printer's Maintenance menu
Fix an inkjet clog	Run “Clean Print Head” once or twice; compare nozzle checks
Revive a dried cartridge	Rest the nozzle strip on a warm damp paper towel a few minutes
Fix a laser blank page	Remove orange sealing tape, rock the toner, reseat firmly
Rule out the document	Print a normal web page or email as your test
Prevent it	Print a page every week or two so the ink doesn't dry
Get help	Call Bill: (330) 200-8042

BEFORE YOU GO

A Note From Bill

A quick note from Bill. I write these guides to make home tech a little less frustrating, and I do my best to keep every step accurate and up to date. Still, every home, device, and setup is a bit different, so I can't promise a guide will match yours exactly or fix your particular problem. These guides are for general information only — they're not professional, legal, or financial advice, and they don't replace your device's own manual or the manufacturer's instructions. Please go slow, use your own good judgment, and use everything here at your own risk. If a step involves electrical wiring, a gas appliance, a water heater, plumbing, or climbing a ladder — or if anything just doesn't feel safe — please stop and call a licensed professional (or give me a call at 330-200-8042). Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results.

HOW I CAN HELP

Your Visit — and My Promise

You don't have to remember all of it — just that a friendly, patient person is one call away, whenever you'd rather have a hand.

KEY SPECS

In your home — $99 flat for the first visit, no contracts and no surprises, with a 30-day come-back-free follow-up. In-home visits cover Portage County, Ohio and nearby communities.
Outside the area? Remotely — $49 for a screen-share session (free for Support Plan members, $39/mo), refundable if I can't fix it — and credited toward a visit if you'd rather have me in person. Book either at billshometech.com/book.

GOOD TO KNOW

My promise — If you're not 100% satisfied with your visit, I'll come back at no charge, or refund the full $99. No questions, no awkwardness. That's how I'd want to be treated.

Whenever you're ready, I'll come to your home anywhere in Portage County, Ohio and nearby communities, at your pace. Too far for a house call? I also help remotely. Book at billshometech.com/book or call (330) 200-8042. — Bill

Call or text (330) 200-8042 · bill@billshometech.com

This free guide is for general information only — not professional advice, and no substitute for your device's own manual. Any prices or outside products mentioned can change; please confirm current details before you buy. Please use your own good judgment and follow it at your own risk — for anything involving electricity, gas, water, or heights, stop and call a licensed professional. Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results. © 2026 Bill's Home Tech, LLC.