BILL'S HOME TECH

Home & Small Business Tech Solutions

AN EXTENDED GUIDE · NO. 2108

Updated November 2026

My Remote / Keyboard / Mouse Stopped Responding

The thing you point or type with has gone dead — here's the quick way to wake it back up

Plain-English tech help from:
Bill's Home Tech
Portage County, Ohio

Tech Made Simple. Service Made Personal.

Bill Davis — Bill's Home Tech
(330) 200-8042 · bill@billshometech.com · Atwater, Ohio

Book a visit · billshometech.com/book

What's Inside

Everything in this guide, with page numbers. Skip to whichever chapter answers your question right now.

The 60-Second Version 3
The Short Version 3
The Usual Suspects 4
Start With the Batteries 4
For a TV or Cable Remote 5
For a Wireless Keyboard or Mouse With a USB Dongle 6
For a Bluetooth Keyboard, Mouse, or Remote 6
Check It's Actually Switched On 7
Restart the Device It Controls 8
Interference and Distance 8
Clean It and Free Stuck Buttons 9
Use Your Phone or a Backup in the Meantime 9
When It's Really the Controller 10
When to Call Bill 10
Everyday Cheat Sheet 12
A Note From Bill 13
Your Visit — and My Promise 14

SUMMARY

The 60-Second Version

A remote, keyboard, or mouse that stops responding has almost always lost power or its connection — it's rarely broken. Start with fresh batteries from a sealed package, since weak batteries are the number-one cause. For a TV remote, point it straight at the set and check the tip glows through a phone camera.

For a wireless keyboard or mouse, reseat the little USB receiver and check for an on/off switch underneath; for a Bluetooth one, reconnect or re-pair it in the device's Bluetooth settings. Restarting the TV or computer it controls restores many stubborn connections. Meanwhile, the maker's phone app or a spare wired keyboard keeps you going.

If all that fails, a replacement controller is cheap — the device itself is fine.

1 The Short Version

Remotes, keyboards, and mice are simple devices that talk to your TV or computer wirelessly, and when one stops responding it's almost always one of a few small things: dead or weak batteries, a lost wireless connection, something blocking the signal, or an unplugged receiver. A truly broken controller is the rarest cause of all.

Work through the short list below and you'll have it responding again in minutes most of the time — usually at the very first step, which is simply fresh batteries.

- Batteries are the number-one cause — try fresh ones before anything else.
- Wireless controllers can lose their pairing and need reconnecting.
- A tiny USB receiver unplugged or loose will kill a wireless keyboard or mouse.
- Restarting the device being controlled often restores a stubborn connection.

TIP

Before anything clever, swap in fresh batteries from a package you know is good — not ones from a drawer that might be just as dead. Weak batteries are behind the great majority of unresponsive remotes and wireless keyboards, and fresh ones are a thirty-second test.

2 The Usual Suspects

Knowing the short list of causes makes the whole thing far less mysterious. Nearly every unresponsive controller comes down to one of these.

- Batteries: dead, weak, or put in the wrong way around.
- Lost connection: a wireless or Bluetooth controller forgot its pairing.
- Blocked signal: something between the controller and the device, or too much distance.
- Unplugged receiver: the little USB dongle a wireless keyboard or mouse relies on came loose.
- A power switch: many keyboards and mice have an on/off switch that got nudged off.

GOOD TO KNOW

The good news hidden in this list is that almost none of these are the controller actually breaking. They're connections and power — things you can check and fix yourself in a couple of minutes.

3 Start With the Batteries

Because batteries cause most of these problems, always start here, and start properly — with batteries you're sure are fresh. It's the fastest, cheapest test there is.

1. Open the battery compartment (usually a slide-off cover on the back or underside).
2. Take out the old batteries and put in fresh ones from a new package.

3. Check they're facing the right way — match the plus and minus marks inside the compartment.
4. Close it up and test the controller.
5. If it uses a rechargeable battery, plug it in to charge for a while and try again.

> **TIP**
> Batteries from a drawer can be as flat as the ones you're replacing, which leads people to wrongly conclude the remote is broken. Test with batteries from a fresh, sealed package to be certain — it rules out the number-one cause cleanly.

4 For a TV or Cable Remote

A traditional remote sends an invisible beam to the TV, so a clear line of sight and a little reset often do the trick when batteries aren't the issue.

1. Point the remote straight at the TV with nothing blocking the path.
2. Make sure you're close enough — a few feet, not across a large room, while testing.
3. Take the batteries out, press and hold any button for ten seconds to clear it, then reinsert the batteries.
4. Clean the little window at the front tip of the remote, where the signal comes out, with a dry cloth.
5. Try the TV's own buttons to confirm the TV itself is working.

> **GOOD TO KNOW**
> You can often check a traditional remote with a phone camera: point the remote's front tip at the camera, press a button, and look at the screen — many cameras show the invisible beam as a faint flicker. A flicker means the remote is sending; no flicker points to the remote.

5 For a Wireless Keyboard or Mouse With a USB Dongle

Many wireless keyboards and mice talk to the computer through a tiny USB receiver plugged into it. If that receiver comes loose or the batteries die, the controller goes silent.

1. Check the little USB receiver is firmly plugged into the computer; reseat it in a different USB socket.
2. Replace the batteries in the keyboard or mouse with fresh ones.
3. Look for an on/off switch on the underside of the mouse or edge of the keyboard, and make sure it's on.
4. Some have a small "connect" or "pair" button — press it, and the matching one on the receiver if there is one.
5. Move the receiver closer, or to a front USB port, if the signal seems weak.

> **TIP**
>
> Plugging the USB receiver into a different socket, ideally one on the front of a desktop computer or not hidden behind other cables, often cures a flaky wireless keyboard or mouse. Distance and obstructions matter more than people expect.

6 For a Bluetooth Keyboard, Mouse, or Remote

Some controllers connect by Bluetooth rather than a dongle, and these occasionally lose their pairing and need reconnecting. It sounds technical but is a short, safe process.

1. Make sure the controller is charged or has fresh batteries, and is switched on.
2. On the device it controls, open the Bluetooth settings and see if the controller shows as connected.
3. If it's listed but not connected, select it to reconnect; if it won't, remove ("forget") it and pair it again.

4. To pair, put the controller into pairing mode (often a held button until a light blinks) and select it on the device.
5. Keep the two close together while pairing.

> **GOOD TO KNOW**
>
> Bluetooth controllers can drop their connection after the device restarts, a battery dies, or they're used with another device. Reconnecting or re-pairing is routine housekeeping, not a sign anything's broken.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

7 Check It's Actually Switched On

It sounds almost too simple, but many wireless keyboards and mice have a power switch that's easy to knock off — and a controller that's switched off looks exactly like a dead one.

1. Turn the mouse over and look for a small switch on its underside.
2. Check the edges and back of a keyboard for an on/off switch.
3. Make sure any power indicator light comes on when it's switched on.
4. For a rechargeable one, confirm it actually has charge.

> **TIP**
>
> A mouse switched off during cleaning or in a bag is a classic "it died" that's really just an off switch. Always flip it over and check that little switch before concluding anything's wrong.

8 Restart the Device It Controls

Sometimes the controller is fine and it's the TV or computer that's lost track of it. A restart of the device being controlled re-establishes the connection surprisingly often.

1. Restart the computer, or unplug the TV for 30 seconds and plug it back in.
2. Let it fully start up before testing the controller again.
3. For a wireless keyboard or mouse, reconnect the receiver after the restart if needed.
4. Test the controller once everything's back.

> **GOOD TO KNOW**
>
> A frozen or confused computer will ignore a perfectly good keyboard and mouse. If neither responds at all, suspect the computer itself is frozen — a force restart (holding its power button) may be needed to wake it.

9 Interference and Distance

Wireless controllers can be thrown off by distance, obstructions, and interference from other electronics. A few adjustments often restore a shaky connection.

- Move closer to the device while testing, to rule out distance.
- Clear objects between the controller and the device or its receiver.
- Keep the receiver away from other wireless gadgets and metal that can block signals.
- A controller used on a thick metal desk or far from the computer may struggle.

> **TIP**
>
> If a mouse works fine near the computer but gets jerky farther away, it's a signal-strength issue, not a fault. Moving the USB receiver to a nearer or less-obstructed socket usually smooths it right out.

10 Clean It and Free Stuck Buttons

A controller that responds erratically — some buttons work, a key sticks, the pointer jumps — may just be dirty. A gentle clean often restores it.

1. Wipe the controller with a dry or barely-damp cloth; crumbs and grime block buttons and sensors.
2. For a mouse, clean the little sensor window on its underside, and use it on a proper surface or mouse pad.
3. Gently work any sticky button to free it; a stuck button can block a remote entirely.
4. Shake out crumbs from a keyboard by turning it upside down and tapping it.

> **GOOD TO KNOW**
>
> A single stuck button can make a whole remote seem dead, because the remote thinks that button is always being pressed. Freeing a sticky button sometimes revives a remote that looked finished.

11 Use Your Phone or a Backup in the Meantime

While you sort out a dead controller, you're often not stuck — there's usually a backup way to carry on. This takes the pressure off the fix.

- Most streaming devices and smart TVs have a free phone app that works as a remote.
- A spare basic wired USB keyboard or mouse will get a computer going again instantly.
- On-screen keyboards let you type with the mouse, or the mouse pointer can be controlled by keyboard in a pinch.
- A TV's own buttons (on the back or underside) cover the basics without any remote.

WATCH OUT

The maker's phone app is a brilliant backup for a lost TV or streaming remote — it does everything the physical remote does, so you're never truly stuck while you hunt for batteries. The remote guides cover setting it up.

12 When It's Really the Controller

If fresh batteries, a reconnect, and a clean all fail, the controller itself may finally have given up — and the good news is that controllers are among the cheapest things to replace.

- A universal remote or the maker's replacement remote is inexpensive and easy to set up.
- Replacement keyboards and mice, wired or wireless, are cheap and plug-and-play.
- The phone app can serve as a permanent remote if you'd rather not replace it.
- A failing controller never means the TV or computer itself is broken.

GOOD TO KNOW

Don't let a dead remote make you think you need a new TV. A replacement or universal remote, or the free phone app, restores full control for a tiny fraction of the cost — the expensive device is perfectly fine.

13 When to Call Bill

You can safely try all of these steps, and most unresponsive controllers come back to life with fresh batteries or a quick reconnect. But if new batteries, a re-pair, and a restart all fail, if you're unsure how to pair a Bluetooth controller, or if several controllers have stopped at once, there's no need to struggle.

I come to you, get your remotes, keyboards, and mice responding again, set up a reliable backup like the phone app, and if something genuinely needs replacing I'll help you pick a simple, inexpensive one and set it up so it just works.

- Fresh batteries, re-pairing, and a restart all fail to revive it.
- You'd like help pairing a Bluetooth keyboard, mouse, or remote.
- Several controllers have stopped responding around the same time.
- You'd like a dependable backup remote or controller set up.

CHEAT SHEET

Everyday Cheat Sheet

Remote, keyboard, or mouse gone dead? Start with batteries — the number-one cause by far.

I want to...	Do this...
Fix it fastest	Put in fresh batteries from a sealed package (not ones from a drawer)
Revive a TV remote	Point it straight at the TV; check the tip glows via a phone camera
Fix a wireless keyboard/mouse	Reseat the little USB receiver; check the on/off switch underneath
Reconnect a Bluetooth one	In Bluetooth settings, reconnect or "forget" and pair it again
Restore a stubborn link	Restart the TV or computer it controls
Carry on meanwhile	Use the maker's phone app, or a spare wired keyboard/mouse
Get help	Call Bill: (330) 200-8042

BEFORE YOU GO

A Note From Bill

A quick note from Bill. I write these guides to make home tech a little less frustrating, and I do my best to keep every step accurate and up to date. Still, every home, device, and setup is a bit different, so I can't promise a guide will match yours exactly or fix your particular problem. These guides are for general information only — they're not professional, legal, or financial advice, and they don't replace your device's own manual or the manufacturer's instructions. Please go slow, use your own good judgment, and use everything here at your own risk. If a step involves electrical wiring, a gas appliance, a water heater, plumbing, or climbing a ladder — or if anything just doesn't feel safe — please stop and call a licensed professional (or give me a call at 330-200-8042). Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results.

HOW I CAN HELP

Your Visit — and My Promise

You don't have to remember all of it — just that a friendly, patient person is one call away, whenever you'd rather have a hand.

KEY SPECS

In your home — $99 flat for the first visit, no contracts and no surprises, with a 30-day come-back-free follow-up. In-home visits cover Portage County, Ohio and nearby communities.
Outside the area? Remotely — $49 for a screen-share session (free for Support Plan members, $39/mo), refundable if I can't fix it — and credited toward a visit if you'd rather have me in person. Book either at billshometech.com/book.

GOOD TO KNOW

My promise — If you're not 100% satisfied with your visit, I'll come back at no charge, or refund the full $99. No questions, no awkwardness. That's how I'd want to be treated.

Whenever you're ready, I'll come to your home anywhere in Portage County, Ohio and nearby communities, at your pace. Too far for a house call? I also help remotely. Book at billshometech.com/book or call (330) 200-8042. — Bill

Call or text (330) 200-8042 · bill@billshometech.com

This free guide is for general information only — not professional advice, and no substitute for your device's own manual. Any prices or outside products mentioned can change; please confirm current details before you buy. Please use your own good judgment and follow it at your own risk — for anything involving electricity, gas, water, or heights, stop and call a licensed professional. Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results. © 2026 Bill's Home Tech, LLC.