BILL'S HOME TECH

Home & Small Business Tech Solutions

AN EXTENDED GUIDE · NO. 2180

Updated November 2026

Set the Right Default Printer (and Stop the Wrong One)

End the "it won't print" mystery — point your computer at the right printer for good

Plain-English printer help from:

Bill's Home Tech

Portage County, Ohio

Tech Made Simple. Service Made Personal.

Bill Davis — Bill's Home Tech

(330) 200-8042 · bill@billshometech.com · Atwater, Ohio

Book a visit · billshometech.com/book

What's Inside

Everything in this guide, with page numbers. Skip to whichever chapter answers your question right now.

The 60-Second Version 3

The Short Version 3

Why the Wrong Printer Keeps Getting Picked 4

Turn Off "Let Windows Manage My Default" 4

Set Your Default on Windows 5

Set Your Default on a Mac 5

Clear Out Ghost and Duplicate Printers 6

The "Print to PDF" and "OneNote" Confusion 6

Fax Entries and Other Odd Ones 7

Rename Printers So You Can Tell Them Apart 8

Check the Default Before You Print 8

Setting the Default on a Phone or Tablet 9

When Different Programs Pick Different Printers 9

Reset the Printing System as a Last Resort 10

When to Call Bill 11

Everyday Cheat Sheet 12

A Note From Bill 13

Your Visit — and My Promise 14

SUMMARY

The 60-Second Version

Often "it won't print" means the computer sent the page to the wrong place — an old printer, a "Print to PDF" option, or a fax entry. The fix is to set the right default printer. On Windows, first turn OFF "Let Windows manage my default printer" (which keeps changing it), then click your printer and choose "Set as default."

On a Mac, use the "Default printer" drop-down in Printers & Scanners and pick yours by name rather than "Last Printer Used." Clear out ghost and duplicate printers to leave one obvious choice, and avoid the fake "printers" like Print to PDF, OneNote, and Fax. A glance at the print window before clicking catches the rest.

- Removing a printer from the list does no harm — tidy it down to what you use.
- Give printers plain names like "Kitchen Printer" so the right one is easy to spot.

1 The Short Version

You hit Print, the page never comes out, and it turns out the computer quietly sent it to the wrong place — an old printer you no longer own, a "print to PDF" option, or a fax entry you never use. This is one of the most common reasons "it won't print," and it is not a fault with your printer at all. The cure is to set the right printer as your default, so the computer always reaches for it first.

This guide shows you how to set your default on Windows and a Mac, clear out the ghost copies that cause the confusion, and recognize the odd entries (Print to PDF, OneNote, Fax) that masquerade as printers. Once it is set correctly, printing becomes predictable again.

- "It won't print" is often the computer sending the page to the wrong printer.
- Setting your everyday printer as the "default" fixes it for good.
- Ghost copies of old printers are the usual source of the confusion — clear them out.
- "Microsoft Print to PDF," "OneNote," and "Fax" look like printers but are not — don't pick those.

TIP

On Windows there is a setting called "Let Windows manage my default printer" that quietly switches your default to whatever you last used. Turning it off is often the whole fix — it lets your chosen printer stay the default and stop moving.

2 Why the Wrong Printer Keeps Getting Picked

Your computer keeps a list of every printer it has ever met — your current one, the one from two computers ago, the office printer you used once, and a few built-in options that are not real printers at all. When you print, it sends the job to whichever one is marked "default," and if that default is wrong or keeps changing, your pages vanish into the wrong place.

The confusion usually comes from one of two things: old ghost printers cluttering the list, or a Windows setting that keeps changing your default on its own. Both are easy to put right once you know they exist.

GOOD TO KNOW

A "default" printer is simply the one your computer uses automatically unless you tell it otherwise. Getting this one setting right removes a surprising amount of everyday printing frustration.

3 Turn Off "Let Windows Manage My Default"

On Windows, a well-meaning feature can be the whole problem. "Let Windows manage my default printer" makes the default follow whatever you printed to last — so if you once printed to PDF or to a friend's printer, that becomes your new default without your knowing.

1. Open Settings, then Bluetooth & devices, then Printers & scanners.
2. Scroll down and look for "Let Windows manage my default printer."

3. Turn that switch OFF.
4. Now set your real printer as the default (next chapter) and it will stay put.

> **TIP**
> Turning this off is the single most effective fix for a default that keeps wandering. With it off, the printer you choose stays chosen until you deliberately change it.

4 Set Your Default on Windows

With that setting off, tell Windows exactly which printer to use by default. It takes a moment and sticks.

1. In Settings Bluetooth & devices Printers & scanners, click your everyday printer.
2. Choose "Set as default."
3. Confirm a green check or "Default" label now appears next to that printer.
4. Open any document and print a test page to confirm it goes to the right place.

> **GOOD TO KNOW**
> If "Set as default" is greyed out, the "Let Windows manage" setting from the previous chapter is probably still on — turn it off first, then the option becomes available.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

5 Set Your Default on a Mac

The Mac makes this straightforward with a single drop-down, and it stays set.

1. Open System Settings, then Printers & Scanners.
2. Find the "Default printer" drop-down near the top.

3. Choose your everyday printer from the list (avoid "Last Printer Used" if you want it to stay fixed).
4. Print a test page to confirm.

> **TIP**
> On a Mac, if the drop-down is set to "Last Printer Used," your default will keep changing just like the Windows setting does. Pick your actual printer by name instead to lock it in place.

6 Clear Out Ghost and Duplicate Printers

The biggest source of wrong-printer confusion is a list cluttered with old copies: the same printer listed three times, a printer from a previous house, or one with a cryptic code after its name. Clearing these out leaves one obvious choice and makes printing foolproof.

1. Open your Printers & scanners list (Windows) or Printers & Scanners (Mac).
2. Identify the printers you no longer own or that are clearly duplicates.
3. Remove each one (Windows: click it Remove; Mac: click it Remove / minus –).
4. Leave only your current printer, then set it as default.

> **WATCH OUT**
> Removing a printer from the list does no harm — it only clears the computer's memory of it. If you remove one you did need, you can simply add it back. So do not be timid about tidying the list down to what you actually use.

7 The "Print to PDF" and "OneNote" Confusion

Among your "printers" you will likely see a few that are not printers at all. They are useful tools, but picking one by accident sends your page nowhere physical — which feels exactly like a printer that won't print.

- "Microsoft Print to PDF" (Windows) or "Save as PDF" (Mac): saves a digital file instead of printing — handy on purpose, baffling by accident.
- "Microsoft XPS Document Writer": an old file-saving option almost nobody needs.
- "OneNote" or "Send to OneNote": sends the page into a note-taking app, not to paper.

> **GOOD TO KNOW**
>
> If you hit Print and were asked to "save a file" or name a document instead of getting paper, you almost certainly picked one of these by mistake. Just choose your real printer from the list and try again.

8 Fax Entries and Other Odd Ones

Many all-in-one printers add a separate "Fax" entry to the printer list, and some software adds its own entries too. These can sit right next to your real printer and get picked by accident.

- A "(Fax)" version of your printer sends a fax, not a printout — skip it unless you mean to fax.
- Some printers list both a plain name and one with "IPP" or a long code; either usually prints, but pick one and set it as default to avoid confusion.
- If an entry's name means nothing to you and you never chose it, it is safe to remove.

> **TIP**
>
> When two entries clearly point to the same physical printer, keep the one with the plainer name, set it as default, and remove the other. One clear choice beats three confusing ones every time.

9 Rename Printers So You Can Tell Them Apart

If you genuinely use more than one printer — say one at home and one you connect to elsewhere — giving them clear, plain names makes choosing the right one effortless.

1. Open your printer's settings (Windows: click the printer Printer properties; Mac: Printers & Scanners select see its options).
2. Look for the name field and change it to something obvious, like "Living Room HP" or "My Printer."
3. Save, and the friendly name now appears wherever you print.

> **GOOD TO KNOW**
>
> A clear name like "Kitchen Printer" is far easier to spot in a hurry than "HP OfficeJet Pro 8025e (A1B2C3)." A minute of renaming pays off every time you print.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

10 Check the Default Before You Print

Even with everything set correctly, a quick glance at the print window before you click Print is a good habit — it catches the rare case where the wrong printer slipped in, before you waste a moment wondering where the page went.

- When the print window opens, look at the printer name shown at the top.
- If it is not your printer, click the name and pick the right one from the drop-down.
- Then print — and the page goes exactly where you expect.

TIP

This one-second check is the simplest insurance against a lost printout. Make it a habit and "where did my page go?" largely disappears from your life.

11 Setting the Default on a Phone or Tablet

Phones and tablets handle default printers more simply, but the same idea applies — the right printer should come up first when you print.

- On an iPhone or iPad, the Print screen remembers your last-used printer and offers it first — just confirm it is the right one.
- On an Android phone, the print service lists available printers; pick yours, and it is usually remembered next time.
- As always, the phone and printer must be on the same Wi-Fi for the printer to appear.

GOOD TO KNOW

Phones rarely suffer the ghost-printer clutter that computers do, so once your printer shows up and prints, it generally keeps offering the right one without any fuss.

12 When Different Programs Pick Different Printers

Occasionally you set your default correctly, yet one particular program — say an email app or a photo program — still reaches for the wrong printer. That is because some programs remember their own last-used printer separately from the system default. It is easily tamed once you know to look.

1. When you print from that program, open its print window and check the printer name at the top.
2. If it is wrong, change it to your printer right there in that program's print window.

3. Many programs remember your choice for next time once you have corrected it once.
4. If a program keeps forgetting, check inside its own settings for a "default printer" option.

> **GOOD TO KNOW**
>
> The system default covers most of your printing, but a stubborn program with its own memory is why the occasional page still goes astray even after you set things up. Correcting it once inside that program usually teaches it to behave.

13 Reset the Printing System as a Last Resort

If your printer list has become such a tangle that removing and re-adding will not sort it — printers that refuse to leave, duplicates that keep returning, or a default that will not hold — there is a stronger option that wipes the whole list clean so you can start fresh with just your real printer.

1. On a Mac, open Printers & Scanners, right-click (or Control-click) anywhere in the printer list, and choose "Reset printing system" — this removes every printer at once.
2. On Windows, the equivalent is clearing the stuck printing helper: restart the "Print Spooler" from the Services app, or run the built-in Printer troubleshooter.
3. After resetting, add back only your current printer and set it as the default.
4. Print a test page to confirm the clean setup works.

> **WATCH OUT**
>
> "Reset printing system" on a Mac is powerful — it erases every printer and its settings in one stroke — so it is a genuine last resort, not an everyday fix. If your list is badly tangled and you are nervous about wiping it, this is a good one to do together so nothing you need is lost.

14 When to Call Bill

Setting the right default printer and clearing out the ghosts is quick once you know where to look, and it cures a surprising share of "it won't print" complaints. But if your printer list is a tangle of old copies, if the default keeps changing no matter what, or if you simply want it set up cleanly once and for all, I am glad to sort it.

On a visit I will tidy your printer list down to what you actually use, set the right default so it stays put, give your printers clear names, and leave printing predictable. It is a small cleanup that quietly ends a lot of daily frustration.

- Your printer list is cluttered with old or duplicate copies.
- The default keeps changing on its own despite your best efforts.
- Pages keep going to "Print to PDF," a fax entry, or nowhere at all.
- You would like it set up cleanly and labeled so it is foolproof.

CHEAT SHEET

Everyday Cheat Sheet

Keep this by the computer. One clear default ends the mystery.

I want to...	Do this...
Stop the default wandering	Windows: turn OFF "Let Windows manage my default printer"
Set your default (Windows)	Printers & scanners click your printer Set as default
Set your default (Mac)	Printers & Scanners "Default printer" drop-down pick yours by name
Clear the confusion	Remove old and duplicate printers — it does no harm
Avoid the fake printers	Don't pick "Print to PDF," "OneNote," or "(Fax)" by accident
Catch it every time	Glance at the printer name in the print window before clicking Print
Get help	Call Bill: (330) 200-8042

BEFORE YOU GO

A Note From Bill

A quick note from Bill. I write these guides to make home tech a little less frustrating, and I do my best to keep every step accurate and up to date. Still, every home, device, and setup is a bit different, so I can't promise a guide will match yours exactly or fix your particular problem. These guides are for general information only — they're not professional, legal, or financial advice, and they don't replace your device's own manual or the manufacturer's instructions. Please go slow, use your own good judgment, and use everything here at your own risk. If a step involves electrical wiring, a gas appliance, a water heater, plumbing, or climbing a ladder — or if anything just doesn't feel safe — please stop and call a licensed professional (or give me a call at 330-200-8042). Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results.

HOW I CAN HELP

Your Visit — and My Promise

You don't have to remember all of it — just that a friendly, patient person is one call away, whenever you'd rather have a hand.

KEY SPECS

In your home — $99 flat for the first visit, no contracts and no surprises, with a 30-day come-back-free follow-up. In-home visits cover Portage County, Ohio and nearby communities.
Outside the area? Remotely — $49 for a screen-share session (free for Support Plan members, $39/mo), refundable if I can't fix it — and credited toward a visit if you'd rather have me in person. Book either at billshometech.com/book.

GOOD TO KNOW

My promise — If you're not 100% satisfied with your visit, I'll come back at no charge, or refund the full $99. No questions, no awkwardness. That's how I'd want to be treated.

Whenever you're ready, I'll come to your home anywhere in Portage County, Ohio and nearby communities, at your pace. Too far for a house call? I also help remotely. Book at billshometech.com/book or call (330) 200-8042. — Bill

Call or text (330) 200-8042 · bill@billshometech.com

This free guide is for general information only — not professional advice, and no substitute for your device's own manual. Any prices or outside products mentioned can change; please confirm current details before you buy. Please use your own good judgment and follow it at your own risk — for anything involving electricity, gas, water, or heights, stop and call a licensed professional. Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results. © 2026 Bill's Home Tech, LLC.