BILL'S HOME TECH

Home & Small Business Tech Solutions

AN EXTENDED GUIDE · NO. 2418

Updated November 2026

TV Sound Too Low or Out of Sync — How to Fix It

Quiet sound, mumbled voices, or lips that don't match — the settings that fix each

Plain-English tech help from:

Bill's Home Tech

Portage County, Ohio

Tech Made Simple. Service Made Personal.

Bill Davis — Bill's Home Tech

(330) 200-8042 · bill@billshometech.com · Atwater, Ohio

Book a visit · billshometech.com/book

What's Inside

Everything in this guide, with page numbers. Skip to whichever chapter answers your question right now.

The 60-Second Version 3
The Short Version 3
What's Really Going On 4
First, Figure Out Which Problem You Have 5
Where Is Your Sound Coming From? 5
Turn It Up the Right Way 6
Settings That Quietly Lower Your Volume 7
When Dialogue Is Hard to Hear 8
Turn On Captions as a Safety Net 8
Sound a Beat Behind the Picture — Fix Lip-Sync 9
Soundbar and Receiver Sync 10
Bluetooth Audio Lag 11
Is It the Show, the TV, or the Soundbar? 11
Check the Cables and Connections 12
Set It Up So It Stays Right 13
When to Call Bill 14
Everyday Cheat Sheet 15
A Note From Bill 16
Your Visit — and My Promise 17

SUMMARY

The 60-Second Version

First, name the problem. Too quiet: open the sound menu and turn OFF "night mode," "auto volume," and "compression," which quietly hold the sound down — and if you have a soundbar, use ITS remote for volume. Voices mumbled: switch on a "Clear Voice" or "Dialogue" mode and turn captions on.

Out of sync: find the "Audio Delay" or "Sync" setting and nudge it (if the sound is late, lower the delay; if early, raise it). Bluetooth headphones always have a little lag — that is normal. To tell where the fault lives, switch channels or apps: a problem on everything is your settings, a problem on only one show is that source.

A silent soundbar is usually plugged into the wrong HDMI socket — it needs the one marked ARC or eARC.

1 The Short Version

The picture on your TV looks perfect, but the sound is letting you down. Maybe it is simply too quiet, so you keep reaching for the volume and it is never quite enough. Maybe the voices are muffled while the music and bangs are far too loud.

Or maybe the words are arriving a beat after the lips move, like a badly dubbed film. All three are common, none of them is your fault, and all three can usually be fixed from the comfort of your chair without buying a single thing.

The trick is to work out which of those three problems you actually have, because each one has its own cure. This guide takes them one at a time, in plain English, and shows you the settings that quietly cause each one — settings that are almost always switched the wrong way by default.

- Too quiet? A "night" or "auto volume" setting is usually the culprit, and turning it off often brings the sound roaring back.

- Voices hard to follow? A "clear voice" or "dialogue" mode, plus captions, makes a world of difference.
- Sound a beat behind the picture? That is "lip-sync," and there is a single audio-delay setting made to fix it.
- First, know where your sound comes from — the TV's own speakers, a soundbar, or a receiver — because that is where the fix lives.
- When the menus feel like a maze, this is a quick, welcome call for Bill.

> **TIP**
>
> Before you change anything, find the right remote. If you have a soundbar or a sound system, its volume is controlled by ITS remote, not the TV's — and pressing the wrong one is behind a surprising number of "the sound won't go up" puzzles.

2 What's Really Going On

It helps to know why good televisions so often sound poor, because then none of this feels like something you broke. Modern TVs are astonishingly thin, and there is simply no room inside for the large speakers that made older sets sound full. The speakers that do fit are small and usually fire downward or backward, away from you, so the sound can seem thin and far-off even when everything is working perfectly.

On top of that, the picture and the sound travel through the TV by slightly different paths. The picture can take an extra fraction of a second to process for all its sharpening and smoothing, and if the sound does not wait for it, the two drift apart — that is the lip-sync delay. And several "helpful" settings, switched on at the factory, actually hold your volume down or flatten the sound.

So most sound trouble is not a fault at all. It is a setting, a path, or the laws of physics in a very thin box — all of it adjustable.

> *Most TV sound problems are a setting switched the wrong way, not a broken speaker. That is good news: settings are free to change back.*

3 First, Figure Out Which Problem You Have

The fastest way through this guide is to name your problem precisely, because each of the three has a different cure and you only need the chapter that matches yours. Read these three descriptions and pick the one that fits.

- TOO QUIET: everything is low, even turned all the way up, or it varies wildly — whispers you cannot hear, then adverts that blast. Head for the volume and night-mode chapters.
- DIALOGUE UNCLEAR: the overall volume is fine, but the talking is mumbly and swamped by background music and effects. Head for the clear-voice and captions chapters.
- OUT OF SYNC: the sound is clear and loud enough, but it lands a beat after the mouths move. Head for the lip-sync and soundbar-sync chapters.

GOOD TO KNOW

It is perfectly possible to have two of these at once — quiet AND out of sync, for instance. If so, fix them one at a time, starting with whichever bothers you most. Changing one setting at a time is also how you can tell what actually helped, rather than changing five things and never knowing which one was the cure.

4 Where Is Your Sound Coming From?

Before you change a setting, be clear about which device is actually making the sound, because that is where the fix has to happen. There are three common setups, and the menus you need live in different places for each.

- The TV's own speakers: sound comes straight out of the television. You adjust it in the TV's sound menu.
- A soundbar: a long, slim speaker sitting under or in front of the TV. Its volume and modes are set on the soundbar (often with its own little remote or app), though some settings still live in the TV.
- A receiver or home-theatre system: a larger box with several speakers around the room. Its sound is controlled on the receiver.

1. Turn the volume up and down and listen for where the change happens — that tells you which device is in charge.
2. If pressing the TV remote's volume does nothing, the sound is being handled by a soundbar or receiver, and you need its remote instead.
3. Note which setup you have before you go hunting through menus — it saves a lot of wrong turns.

> **TIP**
>
> If you have a soundbar but the sound is clearly coming from the TV itself (thin and tinny), the soundbar may simply be off, on the wrong input, or not connected — which is its own easy fix, and a common one. Getting the soundbar actually doing the work is often the single biggest improvement of all.

5 Turn It Up the Right Way

This sounds too obvious to mention, but "the volume won't go up" is one of the most common calls there is, and the cause is almost always that two different volume controls are fighting each other. When you have a soundbar or receiver, there are effectively two dials, and they have to be set sensibly together.

1. If you have a soundbar or receiver, turn the TV's OWN volume to a middle-ish level and leave it there — the TV is just passing sound along.
2. Then use the SOUNDBAR'S (or receiver's) remote for your everyday volume. That is the dial that really matters.
3. Check nothing is muted: a mute symbol (often a crossed-out speaker) on either device will silence everything no matter how high you turn it.
4. If one remote does nothing at all, you are holding the wrong one — try the other.

GOOD TO KNOW

If your TV sound only ever comes from the TV speakers (no soundbar), then there is only one volume to worry about, and "it won't go higher" usually points to a night or compression setting holding it down — exactly what the next chapter fixes.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

6 Settings That Quietly Lower Your Volume

Here is the single most common reason a TV sounds too quiet, and almost nobody knows to look for it. Televisions ship with features meant to "even out" the sound or make it gentle for night-time, and while well-meant, they often leave the whole thing feeling muffled and low. Turning them off frequently brings the sound back to life.

These settings hide in the TV's (or soundbar's) sound menu under names that change from brand to brand, so you are looking for the idea rather than an exact word. Open your sound settings and hunt for anything along these lines:

- "Night mode" or "late-night mode" — designed to hush loud moments so you do not wake the house; turn it OFF when you want full volume.
- "Auto volume," "volume leveling," or "automatic volume control" — tries to make everything the same loudness and often ends up flattening it; try it OFF.
- "Dynamic range control" or "compression" — squeezes the loud and quiet together; set it to OFF or "wide" for livelier sound.
- A "sound mode" stuck on something odd like "Music" or "Sport" — "Standard" is a safe starting point for most watching.

TIP

Change one of these at a time and listen for a few seconds before changing the next. That way, if one of them was the fix, you will know exactly which — and you can leave the rest alone.

7 When Dialogue Is Hard to Hear

If the overall volume is fine but you keep missing what people are saying — the words lost under swelling music and sound effects — you are far from alone. It is one of the most common complaints about modern TV and film, the mixes genuinely do bury the dialogue, and TV makers have added settings specifically to pull the voices back out front.

1. Open your TV's (or soundbar's) sound menu and look for a mode with a name like "Clear Voice," "Dialogue," "Speech," "Voice Enhancement," or "Clarity."
2. Turn it on, or raise it, and listen to a few lines of talking to judge the difference.
3. If there is a separate "dialogue level" or "center" slider, nudge it up a notch or two.
4. If you have a soundbar, check for the same kind of voice mode on the soundbar itself — that is often where it lives.

GOOD TO KNOW

These voice modes work by gently lifting the frequencies of human speech while easing back the rumble and crash around it. They are not magic, but on a mumbly film they can turn "what did he say?" into comfortable listening, and they are completely safe to leave on all the time if you like them.

8 Turn On Captions as a Safety Net

There is no shame at all in switching on the subtitles — millions of people watch with them on all the time, and not because they cannot hear. They are the surest way never to miss a line again, they cost nothing, and you can turn them off any time. Think of them as a comfortable safety net rather than an admission of anything.

1. Look for a "Subtitles," "Captions," or "CC" option — often on the remote directly, or in the TV's accessibility or sound settings.
2. Inside a streaming app (such as Netflix or a news app), captions are usually a speech-bubble or "CC" symbol on the playback screen for that show.
3. Turn them on and, if you like, make the text larger or higher-contrast in the caption settings so they are easy to read.

> **WATCH OUT**
>
> Captions and a clear-voice mode together are the belt-and-braces answer for hard-to-follow dialogue. Many people set both once and simply forget about them, and never struggle with a quiet mumbled scene again.

9 Sound a Beat Behind the Picture — Fix Lip-Sync

When the voices land a fraction of a second after the lips move, it is maddening but very fixable. This is called lip-sync delay (or audio delay), and it happens because the picture takes slightly longer to process than the sound does, so they fall out of step. Nearly every TV and soundbar has a single setting made to nudge them back together.

1. Open your TV's (or soundbar's) sound menu and look for "Audio Delay," "Audio Sync," "Lip Sync," "A/V Sync," or "Digital Audio Delay."
2. You will see a slider, usually measured in milliseconds (ms). Play something with lots of talking so you can judge it.
3. If the SOUND is arriving LATE (after the lips), reduce the delay. If the sound is arriving EARLY (before the lips), increase it.
4. Nudge it a little at a time and watch a talking face until the words and the lips line up.

> **GOOD TO KNOW**
>
> If the delay only appears on one app or one channel and everything else is fine, the problem is in that broadcast or that app, not your TV — there is nothing to fix on your end, and it usually sorts itself out. It is when the whole TV is out of sync, all the time, that the audio-delay setting is the answer.

10 Soundbar and Receiver Sync

If your sound comes from a soundbar or a receiver rather than the TV's own speakers, lip-sync problems are especially common, because the sound takes an extra little journey over to that separate device. The good news is that soundbars and receivers almost always have their own audio-delay setting to compensate.

1. Look for the audio-delay or "lip sync" setting on the SOUNDBAR or receiver (in its own menu or phone app), not only on the TV.
2. Adjust it the same way: if the sound is late, reduce the delay; if early, increase it.
3. If both the TV and the soundbar have a delay setting, adjust just one at a time so they do not fight each other.
4. A full off-and-on of the soundbar (unplug it for thirty seconds) clears a surprising number of sync glitches on its own.

WATCH OUT

Be careful not to set a big delay on both the TV and the soundbar at once, as the two can stack up and make things worse. If you have been fiddling and it is now badly off, set both delays back to zero (or default) and start again from there, adjusting only one.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

11 Bluetooth Audio Lag

If you listen through Bluetooth — wireless headphones, wireless earbuds, or a Bluetooth speaker — a slight delay between the picture and the sound is common and has a different cause. Bluetooth has to squeeze the sound into a wireless signal and unpack it at the other end, and that takes a moment, which shows up as lip-sync lag.

- A small, steady Bluetooth delay is normal and often cannot be fully removed — it is the nature of wireless.
- Some TVs have an audio-delay setting that works for Bluetooth too; try nudging it as in the lip-sync chapter.
- Newer headphones and TVs with "low-latency" support have far less lag — worth knowing if you are choosing new headphones.
- A wired connection (headphones plugged into the TV or a headphone adapter) has no lag at all, if the delay drives you to distraction.

> **TIP**
>
> If Bluetooth headphones are only for the person who is hard of hearing while everyone else listens on the TV speakers, a small delay rarely matters — the listener adjusts to it within minutes. It is worth living with for the comfort of hearing clearly without blasting the room.

12 Is It the Show, the TV, or the Soundbar?

A big part of fixing sound is working out WHERE the problem lives, because that tells you whether to change a setting or simply wait it out. The quickest way is to compare: does the problem happen on everything, or only on one show, one app, or one channel?

1. Switch to a different channel or a different app and listen. Is the sound still quiet, mumbly, or out of sync?

2. If the problem is on EVERYTHING it is your TV or soundbar settings (the chapters above are your fix).
3. If the problem is on ONLY ONE show, app, or channel it is that source, not your equipment. The fault is in the broadcast or the app.
4. If it is one app, fully closing and reopening the app, or restarting the TV, often clears it.

> **GOOD TO KNOW**
>
> This single comparison saves a lot of needless menu-diving. There is no point adjusting your audio-delay for hours if the only thing out of sync is one film on one app — that one will come right on its own. Fix settings only for the problems that follow you from channel to channel.

13 Check the Cables and Connections

Sometimes the sound trouble is not a setting at all but the cable carrying the sound, or the socket it is plugged into. This matters most when you have a soundbar or receiver, because the sound has to travel there on a cable, and the wrong socket or a loose plug causes weak sound, no sound, or odd behaviour.

- Most soundbars connect by an HDMI cable into the TV's socket marked "HDMI ARC" or "eARC" — that specific socket is the one that sends sound back out to the soundbar. Using any other HDMI socket often means no sound.
- Some older or simpler setups use a thin "optical" cable (a square connector with a little red light inside) instead.
- A loose or half-seated plug causes crackle, drop-outs, or silence — push each end firmly home.
- If you recently moved things or added a device, a cable may simply have gone into the wrong socket.

WATCH OUT

The ARC/eARC socket business trips up almost everyone, because it is the one HDMI port out of several that sends sound to the soundbar, and it is easy to use the wrong one. If your soundbar is silent or only crackles and you have checked the volume, this connection is very often the cause — and it is exactly the sort of five-minute fix I can sort out on a visit if the labels are not clear.

14 Set It Up So It Stays Right

Once the sound is how you like it, a few minutes of tidying means it stays that way and anyone can use it. These are the small habits that turn "why is the sound wrong again?" into a TV that just works.

- Note which remote controls the everyday volume (the soundbar's, usually) and keep the other one tucked aside so nobody grabs the wrong one.
- Leave your chosen clear-voice mode and any captions on if they help — there is no need to switch them off.
- Write down the two or three settings you changed (night mode off, clear voice on, audio delay set) in case a power cut or update ever resets them.
- If several people use the TV, a quick written note by the remote — "use the black remote for volume" — saves endless confusion.

TIP

A TV update can occasionally reset your sound settings back to the factory ones, which is why a little note of what you changed is worth keeping. If the sound ever suddenly goes wrong again for no reason, an update overnight is a likely culprit, and your note makes putting it right a two-minute job.

15 When to Call Bill

Most TV sound trouble is a setting or a cable, and this guide is written so you can work through it calmly from your chair. But there is no prize for wrestling with menus that seem to be in a foreign language, and some of this — telling an ARC socket apart from the others, getting a soundbar talking to the TV properly, or chasing a stubborn lip-sync across a whole system — is simply faster and far less frustrating with someone beside you who does it every week.

I come to you here in Portage County, listen to exactly what is wrong, find whether it is the volume settings, the clarity, the sync, or a cable in the wrong socket, and set the sound so it is comfortable and clear for good — then I write down what I changed so a stray update can never leave you stranded. With 30+ years of professional experience, there is no TV menu I have not seen the inside of, and no question is too small to ask.

- The sound is too quiet no matter which settings you try.
- A soundbar or sound system is silent, crackly, or clearly not doing its job.
- Voices stay mumbled even with clear-voice and captions on.
- The picture and sound are stubbornly out of step across everything you watch.
- You would simply rather have the whole thing set up right, once, by someone you trust.

CHEAT SHEET

Everyday Cheat Sheet

Keep this by the TV. Find your problem in the left column and do the fix on the right.

I want to...	Do this...
Make the sound louder	Turn OFF night mode / auto-volume / compression in the sound menu
Use the right volume	Soundbar or receiver? Use ITS remote; set the TV's own volume mid-level
Hear voices clearly	Turn on a "Clear Voice"/"Dialogue" mode, and switch captions on
Fix lips out of sync	Sound menu Audio Delay / Sync; sound late = lower it, early = raise it
Fix a silent soundbar	Plug it into the HDMI socket marked ARC/eARC; check it's not muted
Find the real cause	Same problem on every channel = settings; one show only = the source
Handle Bluetooth lag	Some delay is normal; nudge audio delay, or use wired for no lag
Get help	Call Bill: (330) 200-8042

BEFORE YOU GO

A Note From Bill

A quick note from Bill. I write these guides to make home tech a little less frustrating, and I do my best to keep every step accurate and up to date. Still, every home, device, and setup is a bit different, so I can't promise a guide will match yours exactly or fix your particular problem. These guides are for general information only — they're not professional, legal, or financial advice, and they don't replace your device's own manual or the manufacturer's instructions. Please go slow, use your own good judgment, and use everything here at your own risk. If a step involves electrical wiring, a gas appliance, a water heater, plumbing, or climbing a ladder — or if anything just doesn't feel safe — please stop and call a licensed professional (or give me a call at 330-200-8042). Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results.

HOW I CAN HELP

Your Visit — and My Promise

You don't have to remember all of it — just that a friendly, patient person is one call away, whenever you'd rather have a hand.

KEY SPECS

In your home — $99 flat for the first visit, no contracts and no surprises, with a 30-day come-back-free follow-up. In-home visits cover Portage County, Ohio and nearby communities.
Outside the area? Remotely — $49 for a screen-share session (free for Support Plan members, $39/mo), refundable if I can't fix it — and credited toward a visit if you'd rather have me in person. Book either at billshometech.com/book.

GOOD TO KNOW

My promise — If you're not 100% satisfied with your visit, I'll come back at no charge, or refund the full $99. No questions, no awkwardness. That's how I'd want to be treated.

Whenever you're ready, I'll come to your home anywhere in Portage County, Ohio and nearby communities, at your pace. Too far for a house call? I also help remotely. Book at billshometech.com/book or call (330) 200-8042. — Bill

Call or text (330) 200-8042 · bill@billshometech.com

This free guide is for general information only — not professional advice, and no substitute for your device's own manual. Any prices or outside products mentioned can change; please confirm current details before you buy. Please use your own good judgment and follow it at your own risk — for anything involving electricity, gas, water, or heights, stop and call a licensed professional. Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results. © 2026 Bill's Home Tech, LLC.