BILL'S HOME TECH
Home & Small Business Tech Solutions

BILL'S COMPLETE MANUALS

Wi-Fi Extenders & Dead Zones

Finding the weak spots and getting Wi-Fi into every room — explained in plain English

A plain-English guide to Wi-Fi in every room

Take your time — you can't break it

Written for you by Bill — Bill's Home Tech

(330) 200-8042 · BillsHomeTech.com

For any home Wi-Fi · facts current November 2026

What's Inside

This is your manual for Wi-Fi dead zones: the bedroom, basement, back porch or far end of the house where the Wi-Fi gives up. We'll find out why it happens, try the free fixes first, and then walk through every kind of help you can add, from a simple plug-in extender to mesh Wi-Fi and the clever adapters that use the wiring already in your walls. Read it in any order; there's no test, and you can't break a thing by exploring.

Part 1 — Getting Started

1 A Note from Bill
2 What a Dead Zone Is
3 The Words You'll See
4 Start Here: Is It Really a Dead Zone?

Part 2 — Finding the Weak Spots

5 Why Dead Zones Happen
6 The Walk Test with Your Phone
7 Measuring with a Free Speed Test
8 Make a Simple Coverage Map

Part 3 — Free Fixes First

9 Move the Router
10 Restart and Update
11 Fix the Device, Not the House
12 Ask Your Internet Provider First

Part 4 — Your Options

13 Extenders: How They Work
14 Setting Up an Extender
15 Placing an Extender
16 Mesh Wi-Fi vs. Extenders
17 Wired Access Points
18 Powerline Adapters
19 MoCA Adapters: Internet over the TV Cable
20 Which One Fits Your Home?

Part 5 — Buying, Outdoors & Staying Safe

21 Wi-Fi 6, 6E & 7 in Plain English
22 What It Costs
23 Wi-Fi Outdoors
24 Booster Scams & Fake Update Links

25 When an Extender Misbehaves

Part 6 — When to Call Bill & Your Cheat-Sheet

26 When to Call Bill
27 Your Dead-Zone Cheat-Sheet

PART 1

Getting Started

What a dead zone is, the handful of words you'll run into, and a quick check that you're fixing the right problem.

CHAPTER 1

A Note from Bill

Hello, and welcome. If the Wi-Fi works beautifully in the living room but gives up in the bedroom, the basement, the back porch or the far end of the house, this guide is for **you**. That's called a **dead zone**, and nearly every home has one somewhere. It isn't a sign that you did anything wrong.

I'm Bill. Helping folks feel at home with their technology is what I do every day, and I wrote this guide the way I'd explain it sitting beside you at your kitchen table: slowly, in plain English, with nothing taken for granted. If I use a word you don't know, I'll stop and explain it right there.

What you'll be able to do

- Understand **why** the Wi-Fi fades in certain rooms.
- Find the weak spots with nothing more than your phone.
- Try the **free fixes** first, which solve more dead zones than you'd expect.
- Choose sensibly between an **extender**, **mesh Wi-Fi**, a **wired access point**, and adapters that use your home's **electrical wiring** or **TV cable**.
- Set up and place an extender so it actually helps.
- Steer clear of "miracle booster" gadgets and the scams that ride along with them.

You can't break it by exploring

Walking around with your phone, running a speed test, or moving the router a few feet can't hurt anything. If you ever unplug the wrong box, plug it back in and give it five minutes. It will come back.

WHAT THIS DOES FOR YOU

Why this matters

Good Wi-Fi in every room means video calls with family from your favorite chair, a doorbell camera that doesn't drop out, and a streaming show in the bedroom that doesn't freeze. Most of the time, getting there costs less than people fear, and sometimes it costs nothing at all.

And I'm a phone call away

If you get stuck, you're not stuck alone. Call me at **(330) 200-8042** and we'll sort it out together, with no judgment. Now, let's go find those weak spots.

— Bill

CHAPTER 2

What a Dead Zone Is

Your Wi-Fi comes from a box called the **router**. It sends out a radio signal, a bit like a lamp sends out light. Close to the lamp, the room is bright. Far away, around corners and through walls, it gets dim. A **dead zone** is a spot where the Wi-Fi "light" is too dim to use.

What it looks like

- Your phone shows only one Wi-Fi bar, or switches to cellular ("5G" or "LTE") in that room.
- Videos stop to load ("buffering"), or video calls freeze and break up.
- Web pages take a long time, or the device says **No Internet**.
- A camera, doorbell or smart speaker in that spot keeps showing **offline**.

A weak spot or a dead spot?

A **weak spot** has some Wi-Fi, but it's slow or unreliable. A true **dead spot** has none at all. The fixes in this guide help both. Weak spots are often cured by the free fixes in Part 3; true dead spots usually need something added, which Part 4 covers.

> **GOOD TO KNOW**
>
> **Wi-Fi bars are not internet speed**
>
> The bars show how strong the *radio signal* is between your device and the router. They don't measure your internet itself. You can have full bars and still be slow if the internet service is having trouble. That's why Chapter 4, *Start Here: Is It Really a Dead Zone?* helps you tell the two apart.

CHAPTER 3

The Words You'll See

You don't need to memorize these. Come back to this page whenever a word puzzles you.

Word	What it means
Router	The box that makes your Wi-Fi. Often combined with the modem in one box.
Modem / gateway	The box that connects your home to the internet company's line. A **gateway** is a modem and router in one.
Dead zone	A spot in or around the house with little or no usable Wi-Fi.
Extender (repeater, booster)	A small device that catches your router's Wi-Fi and sends it on farther. Most plug straight into a wall outlet.
Mesh Wi-Fi	Two or more matching units placed around the house that work as one network, such as eero, Google Nest Wifi, TP-Link Deco or Netgear Orbi.
Access point	A device that makes Wi-Fi from a wired internet connection, usually an Ethernet cable from the router.
Ethernet	The ordinary network cable, with a plug like a wide phone plug.
Backhaul	The connection between the router and an extender or mesh unit. It can be wireless or wired.
Powerline adapter	A pair of plugs that carry internet over your home's electrical wiring.
MoCA adapter	A pair of boxes that carry internet over the coaxial (TV cable) wiring in your walls.
2.4 GHz / 5 GHz / 6 GHz	The radio "lanes" Wi-Fi uses. 2.4 reaches farthest but is slower; 5 and 6 are faster but don't travel as far through walls.
Wi-Fi 6, 6E, 7	Generations of Wi-Fi, like model years. Higher is newer. Chapter 21, *Wi-Fi 6, 6E & 7 in Plain English* explains.
WPS	A button on many routers and extenders that pairs them without typing a password.

CHAPTER 4

Start Here: Is It Really a Dead Zone?

Before buying anything, make sure the problem is really *where* you are in the house, and not the internet service as a whole. It takes five minutes.

1. Take your phone or tablet and stand in the same room as the router, a few feet away.
2. Run a free speed test (Chapter 7, *Measuring with a Free Speed Test* shows how) and jot down the number.
3. Now go to the problem room and run the same test.
4. Compare. If the number **near the router** is also poor, the trouble is the internet service or the router itself, not a dead zone.
5. If it's good near the router but poor in the problem room, you have a coverage problem. The rest of this guide is for you.

TIP

Slow everywhere?

If it's slow even beside the router, start with the companion manual **Slow Internet? Speed Tests & Fixes**. An extender can't make the internet faster than what arrives at the router; it can only carry that speed farther.

GOOD TO KNOW

Is it one device or all of them?

If only one old tablet struggles in a room where your phone works fine, the tablet may be the weak link. Chapter 11, *Fix the Device, Not the House* covers that.

PART 2

Finding the Weak Spots

Why Wi-Fi fades, and three simple ways to see exactly where it's weak, using only the phone in your pocket.

CHAPTER 5

Why Dead Zones Happen

Wi-Fi is a radio signal, and some things in a house are very good at blocking or soaking up radio signals. Most dead zones come from a mix of the reasons below.

Distance

The signal gets weaker the farther it travels. A router in a corner office at one end of a long ranch house may simply not reach the bedroom at the other end.

Walls, floors and what they're made of

Material	How much it blocks
Wood, drywall, glass windows	A little each. Several in a row add up.
Plaster walls (common in older homes)	Quite a lot, especially old plaster on metal mesh (lath).
Brick, stone, concrete, cinder block	A great deal. Basements and brick fireplaces are classic dead zones.
Floors and ceilings	A lot. Each floor between you and the router weakens the signal.
Metal: appliances, filing cabinets, ductwork, foil-backed insulation	Very strong blocking; metal reflects radio waves.
Water: fish tanks, water heaters, even a full bookcase	More than you'd think.
Mirrors	Many have a metal backing that reflects the signal.

Interference

Some household devices use the same radio lanes as Wi-Fi, especially the 2.4 GHz lane. TP-Link's own placement advice names **microwave ovens**, **cordless phones**, **baby monitors** and **refrigerators** as things to keep away from. Neighbors' Wi-Fi networks on the same lanes can crowd the air too, especially in apartments.

Checked against TP-Link Support on November 13, 2026.

Where the router sits

This is the big one. Routers often end up wherever the internet line comes into the house: a basement corner, a closet, behind the TV, or on the floor behind a couch. Each of those spots wastes a lot of the signal. Chapter 9, *Move the Router* shows how to do better.

CHAPTER 6

The Walk Test with Your Phone

The simplest tool for finding dead zones is already in your pocket. Your phone's Wi-Fi symbol shows signal strength with curved bars: more bars, stronger signal.

Doing the walk

1. Make sure your phone is connected to your home Wi-Fi (not cellular). On most phones, the Wi-Fi symbol is a fan of curved bars at the top of the screen.
2. Start next to the router. You should see full bars.
3. Walk slowly through the house, room by room. Pause for ten seconds in each room so the phone can update.
4. In each room, note the bars: full, two, one, or none. Pay special attention to the places you actually sit.
5. Do the same outside if you use a porch, patio, garage or yard camera.

TIP

Check the places that matter

Test where you actually use things: your reading chair, the bed, the kitchen table, the spot where the doorbell camera or a smart TV lives. A weak hallway doesn't matter; a weak favorite chair does.

GOOD TO KNOW

If the Wi-Fi symbol disappears

If your phone shows **5G**, **LTE** or cellular bars in the corner instead of the Wi-Fi fan, it has dropped off Wi-Fi in that spot, which tells you something too: that's a dead zone.

CHAPTER 7

Measuring with a Free Speed Test

Bars give you a rough idea. A **speed test** gives you a number. It's free and takes about thirty seconds.

Running one

1. On your phone, tablet or computer, open the web browser and go to **speedtest.net** or **fast.com**. (Speedtest by Ookla also has a free app in the App Store and Google Play.)
2. Tap **Go** on speedtest.net. Fast.com starts on its own.
3. Wait for the result. The main number is the **download** speed, in **Mbps** (megabits per second).
4. Write down the number and the room. Repeat in each room you care about.

HEADS UP

Beware of look-alike "speed test" sites

Some search ads lead to pages that run a fake test and then claim your device is "infected" or "needs a booster," with a phone number to call. Type the address yourself. A real speed test never asks for money, a phone call or a download.

What the numbers mean

Download speed	What it's good for
Under 5 Mbps	Email and simple web pages, slowly. Video will struggle.
5 to 25 Mbps	Web browsing, music, standard video, one video call.
25 to 100 Mbps	HD streaming and video calls, a few people at once.
Over 100 Mbps	Plenty for most households, including 4K streaming.

These are rough guides, not rules. What matters most is the **difference** between rooms. If the living room tests at 200 and the bedroom at 8, the bedroom is a weak spot, whatever your plan is.

CHAPTER 8

Make a Simple Coverage Map

Putting your findings on paper turns a vague complaint ("the Wi-Fi's bad upstairs") into a clear picture of what to fix, and it's a great thing to have in hand if you call me or your internet company.

1. On a sheet of paper, sketch your floor plan roughly: boxes for rooms, one sketch per floor.
2. Mark where the router is with an **R**.
3. In each room, write the bars (0 to 3 or 4) and the speed-test number.
4. Circle the rooms that matter and are weak. Those are your targets.
5. Note what's between the router and each weak room: a brick wall, a floor, the kitchen.

WHAT THIS DOES FOR YOU

What the map tells you

If the weak rooms are all on the far side of one brick wall, moving the router might be enough. If they're on another floor, a mesh unit or an access point on that floor may be the answer. If there's a TV cable jack in the weak room, MoCA may be perfect. The map points you to the right fix instead of the most advertised one.

PART 3

Free Fixes First

Before you buy anything: moving the router, restarting and updating it, checking the device, and asking your internet company what's already included.

CHAPTER 9

Move the Router

Where the router sits makes a bigger difference than almost anything you can buy. Moving it even a few feet out of a cabinet or off the floor can turn a weak room into a good one.

The best spot

- **Central.** As close to the middle of the home as the cables allow, rather than in a corner or at one end.
- **Up high.** On a shelf or the top of a bookcase, not on the floor. TP-Link suggests roughly four feet up for its extenders, and the same idea works for routers.
- **In the open.** Not inside a cabinet, a closet, an entertainment center or a desk drawer.
- **Antennas up.** If the router has antennas you can move, point them straight up.
- **Away from troublemakers:** microwaves, cordless phones, baby monitors, refrigerators, mirrors, large metal objects and fish tanks.

Checked against TP-Link Support on November 13, 2026.

Moving it safely

1. Find out what's plugged into the router: usually power, a cable from the modem (or the coax or fiber line if it's a gateway), and maybe a few network cables.
2. If the line from the wall is short, a longer cable of the same kind (Ethernet, or coax for a gateway) from a hardware or electronics store lets you move the router without touching the wall jack.
3. Unplug the power, move the router, reconnect the cables exactly as before, then plug the power back in.
4. Give it five minutes to start up fully, then repeat your walk test (Chapter 6, *The Walk Test with Your Phone*).

HEADS UP

Don't move the wall jack yourself

If the router needs to move to another room, the internet line or a network cable may need to be run there. Your internet company can move the line, sometimes for a fee, and running new cable through walls is a job for a pro. A longer cable along the baseboard is a fine stopgap.

TIP

Basement router? Try just raising it

Many homes have the internet line in the basement. If the router is sitting on the basement floor, putting it up near the ceiling joists, directly below the main living area, often helps the floor above.

CHAPTER 10

Restart and Update

Restart the router and modem

Routers are small computers, and like any computer they sometimes get muddled after running for weeks. A restart is harmless and often clears up flaky Wi-Fi.

1. Unplug the **power** cord from the modem and the router (or the single gateway box).
2. Wait about 30 seconds.
3. Plug the **modem** back in first and wait until its lights settle, usually two to five minutes.
4. Plug the **router** back in and wait another few minutes.
5. Test again.

> HEADS UP
> **Restart, don't reset**
> Use the power cord, not the tiny pin-hole **Reset** button. Reset erases all the router's settings, including your Wi-Fi name and password. The **Wi-Fi Passwords** manual explains the difference.

Update the router's software

Router makers send out software updates (called **firmware**) that fix bugs and security holes and sometimes improve performance. Many newer routers and mesh systems update themselves automatically.

- **App-managed routers and mesh systems** (eero, Google Nest Wifi, TP-Link Deco, Netgear Orbi and Nighthawk): open the app and look for **Updates**, **Firmware** or a notice on the main screen.
- **Routers from your internet company** are usually updated by the company automatically.
- **Older routers with a web page:** look for **Firmware Update** or **Router Update** under **Administration** or **Advanced**.

STAY SAFE

Only update from the router's own app or settings page

Never update a router or extender from a link in an email, text or pop-up. Real updates come from inside the router's own app or settings. (Chapter 24, *Booster Scams & Fake Update Links* explains the scam.)

GOOD TO KNOW

When the router itself is the problem

A router that's many years old may simply be past its prime. If it's from before Wi-Fi 5 (sometimes called 802.11ac), it's likely holding the house back. Replacing an aging router, or asking your provider for a current one, can cure a weak spot on its own.

CHAPTER 11

Fix the Device, Not the House

Sometimes the weak link is the gadget, not the Wi-Fi. If newer phones work fine in a room but one device doesn't, look at that device first.

- **Older devices** have weaker radios. A tablet from many years ago may struggle where a new phone is fine.
- **Update the device.** Software updates for phones, tablets, TVs and streaming sticks often include Wi-Fi fixes.
- **Forget and rejoin the network.** In the device's Wi-Fi settings, choose your network, pick **Forget**, then join again with the password.
- **Mind the TV's position.** A streaming stick tucked behind a TV is surrounded by metal. Many come with a short extension cable to move them out from behind the set; use it.
- **Choose the right lane.** If your router shows two network names (for example **Home** and **Home-5G**), a far-away device may do better on the plain 2.4 GHz one, which reaches farther.

TIP

Phone cases and Wi-Fi

Ordinary plastic and leather cases don't affect Wi-Fi. A case with a metal plate or a thick metal kickstand can. If one phone is weak and the others aren't, try it without the case.

CHAPTER 12

Ask Your Internet Provider First

Before buying anything, call your internet company or open its app. Many providers now offer their own extenders or mesh units that work with the router they gave you, and they're managed in the same app.

An example: Spectrum WiFi Extenders

Spectrum (the main cable provider in much of Portage County) offers **Spectrum WiFi Extenders**, which it used to call WiFi Pods. They work with a Spectrum **Advanced WiFi** router to form a single mesh network. You plug them into wall outlets and set them up and manage them in the **My Spectrum** app.

Spectrum WiFi Extenders	What Spectrum says
Price	$5.00 a month per Extender, per Spectrum's page in November 2026.
How many	Spectrum says two are recommended for most homes, with up to five on one account.
Wi-Fi 7 version	Spectrum offers Wi-Fi 7 Extenders to certain higher-speed plans. Ask whether yours qualifies.

Checked against Spectrum's WiFi Extenders page on November 13, 2026.

The companion manual **Spectrum Internet** walks through the My Spectrum app step by step. Other providers have their own versions; ask what they offer, what it costs each month, and whether you can buy your own equipment instead.

Questions to ask

- "Is my router current, or is a newer one available at no extra charge?"
- "Do you offer extenders or mesh units, and what do they cost each month?"
- "Will your equipment work alongside a mesh system I buy myself?"
- "Is my plan's speed what I'm actually getting near the router?"

GOOD TO KNOW

Renting versus buying

A monthly rental is easy and the provider supports it, but it adds up over the years. Buying your own costs more up front but nothing monthly. Neither is wrong; it depends on how long you'll stay with the provider and how much you'd like someone else to handle it. Chapter 22, *What It Costs* has more.

PART 4

Your Options

Extenders, mesh Wi-Fi, wired access points, powerline adapters and MoCA adapters: how each works, what it's good at, and how to choose.

CHAPTER 13

Extenders: How They Work

A Wi-Fi **extender** (also sold as a repeater or booster) is usually a small box that plugs straight into a wall outlet. It listens to your router's Wi-Fi and repeats it, so the signal reaches farther.

The good

- **Inexpensive** compared with a full mesh system.
- **Works with almost any router**, including the one your internet company gave you.
- **Quick to set up**, often with a single button press.

The trade-offs

- **It can only repeat what it hears.** If you place it where the signal is already weak, it repeats a weak signal.
- **Speed drops.** A basic extender uses the same radio to listen to the router and talk to your devices, so it spends part of its time on each. Expect the extended area to be slower than standing near the router. Better models with extra radio bands lose less.
- **Sometimes a second network name.** Some extenders create a separate name like **Home_EXT**, and your devices may cling to the wrong one as you move around.

GOOD TO KNOW

"Booster" means range, not speed

No extender can make your internet faster than your plan. What it does is carry the Wi-Fi farther. If an ad promises it will "double your internet speed," be suspicious. Chapter 24, *Booster Scams & Fake Update Links* explains.

TIP

Pair brands when you can

Some router makers let their own extenders join the router as one seamless network. TP-Link calls this **OneMesh**: the router and its extenders share a single Wi-Fi name and password, and phones switch between them automatically. It only works between OneMesh-compatible TP-Link routers and extenders, so check TP-Link's compatibility list first.

Checked against TP-Link Support on November 13, 2026.

CHAPTER 14

Setting Up an Extender

Most extenders offer three ways to set up. Use whichever is easiest; the result is the same. Always start by plugging the extender into an outlet **near the router** for setup, then move it later.

Way 1: The WPS buttons (fastest)

1. Plug the extender into an outlet in the same room as the router. Wait until its power light is steady.
2. Press the **WPS** button on the router.
3. Within **two minutes**, press the **WPS** button on the extender (TP-Link says about one second).
4. Wait for the extender's Wi-Fi or signal light to go from blinking to solid. That means it's connected.
5. If your router has separate 2.4 and 5 GHz networks, some extenders need the steps repeated for the second band. The extender's leaflet will say.

Checked against TP-Link and Netgear Support on November 13, 2026.

HEADS UP

When WPS won't work

Many newer routers, including some provider gateways and mesh systems, have no WPS button. Netgear notes WPS doesn't work with a hidden network name or old WEP security. If WPS fails, use the app or the web page instead.

Way 2: The maker's app

- **TP-Link:** the free **Tether** app walks you through it.
- **Netgear:** the free **Nighthawk** app has a **Range Extender** option. During setup it may ask you to join a temporary network named **NETGEAR_EXT**, then choose your home network and type its password.

Way 3: A web browser

Join the extender's temporary setup network on a phone or laptop, then open a browser and go to the address on the extender's leaflet. TP-Link uses **tplinkrepeater.net**; Netgear uses **mywifiext.net**, and its newest Wi-Fi 7 models list **mywifiext.local**. A setup assistant asks you to pick your home network and type its Wi-Fi password.

Checked against TP-Link and Netgear Support on November 13, 2026.

STAY SAFE

Get apps from the official store only

Download the Tether or Nighthawk app from the App Store or Google Play, and check the maker's name under the title. Never install an "extender app" from an ad or a link in a text.

TIP

Have your Wi-Fi password ready

Setup by app or browser needs your home Wi-Fi password. If you don't know it, the **Wi-Fi Passwords** manual shows how to find it on your phone.

CHAPTER 15

Placing an Extender

Placement makes or breaks an extender. The most common mistake is putting it *in* the dead zone. By then, there's no good signal left for it to repeat.

The halfway rule

TP-Link's advice is to plug the extender in **about halfway** between the router and the dead zone, in a spot that's still within good range of the router. Think of a relay race: the extender has to be close enough to catch the baton cleanly.

1. After setup near the router, unplug the extender and move it to an outlet roughly halfway to the weak area.
2. Wait about **two minutes** for its signal light to settle.
3. Check the light. Many extenders show good, fair or weak signal by color or by how many lights are lit; the leaflet explains yours. The maker's app may show a signal meter too.
4. If the signal is weak, move it one outlet **closer** to the router and check again.
5. Once it's happy, do your walk test in the problem room (Chapter 6, *The Walk Test with Your Phone*).

Checked against TP-Link Support on November 13, 2026.

More placement tips

- Use an outlet in the open, not behind a couch or a dresser.
- Keep it away from microwaves, cordless phones, baby monitors, refrigerators, mirrors and large metal objects.
- Up is better than down. An outlet on a kitchen backsplash or a hallway at waist height beats one at floor level behind furniture.
- If the extender has antennas, point them straight up.

Checked against TP-Link Support on November 13, 2026.

TIP

One floor up or down

For a weak room upstairs, an outlet on the stairway landing or the hallway at the top of the stairs often works well: it can still hear the router, and it's near the rooms that need help.

CHAPTER 16

Mesh Wi-Fi vs. Extenders

A **mesh system** replaces (or works alongside) your router with two or more matching units spread around the house. They talk to each other and form **one network with one name**. As you walk from room to room, your phone moves between units without you doing anything.

	Plug-in extender	Mesh Wi-Fi system
Cost	Lower	Higher (you buy two or three units)
Network name	Sometimes a second name	Always one name
Speed in far rooms	Often noticeably slower	Usually better, especially with three-band units
Setup	A button or a short app setup	An app walks you through it, usually 15 to 30 minutes
Managing it	Separate from the router	One app for everything: pause devices, guest Wi-Fi, updates
Best for	One weak room in a modest home	Larger or multi-floor homes, several weak rooms

Common mesh systems

You'll see **eero** (Amazon), **Google Nest Wifi**, **TP-Link Deco**, **Netgear Orbi** and others, plus providers' own versions such as Spectrum's Extenders. The companion manual **eero** covers that system step by step.

GOOD TO KNOW

Using mesh with your provider's gateway

If your internet company's box is a combined modem and router, a mesh system you buy plugs into it. That can leave you with two routers "stacked," which mostly works but can cause odd problems. The usual fix is to put the mesh system in a mode often called **bridge** or **access point** mode, or ask the provider to switch its box to modem-only. It's a good one to do together over the phone.

TIP

Place mesh units like extenders

The halfway rule applies here too: each unit should be within good range of the one before it, and out in the open. The app usually shows whether the placement is good.

CHAPTER 17

Wired Access Points

The most reliable way to put strong Wi-Fi in a far room is to run a network (Ethernet) cable to it and add Wi-Fi there. The device at the end of the cable is called an **access point**. Because it gets its internet through the wire instead of the air, it doesn't lose speed the way a wireless extender does.

Ways to do it

- **A mesh unit with an Ethernet cable** back to the router. Most mesh systems support this, called **wired backhaul**, and it's the gold standard.
- **An extender set to access point mode.** TP-Link suggests this when wireless placement doesn't work: run an Ethernet cable from the router to the extender and set it up as an access point.
- **A dedicated access point** made for the job.

Checked against TP-Link Support on November 13, 2026.

Getting the cable there

If there's already a network jack in the far room, you're in luck: some homes were wired years ago. Otherwise, a cable can run along baseboards or through a basement. Cutting into walls and fishing cable between floors is work for a professional low-voltage installer or electrician. If running a new cable isn't practical, the next two chapters show how to use wiring you already have.

CHAPTER 18

Powerline Adapters

Powerline adapters come in pairs and send your internet through the **electrical wiring** in your walls. One plugs into an outlet near the router and connects to it with a short network cable. The other plugs into an outlet in the far room. Some models make Wi-Fi in that room; others give you a network jack for a TV or computer.

Setting them up

1. Plug the first adapter into a wall outlet near the router and connect it to a spare port on the router with a network cable.
2. Plug the second adapter into a **wall outlet** in the room that needs help.
3. If they don't pair on their own, press the **Pair** button on each, within the time the leaflet gives.
4. Wait for the **Powerline** light to come on. Then connect your device by cable, or join the adapter's Wi-Fi if it has it.

Checked against TP-Link Support on November 13, 2026.

HEADS UP

Plug them straight into the wall

TP-Link says to plug powerline adapters **directly into a wall outlet**, never into a power strip, extension cord or surge protector. Surge protectors filter out electrical "noise," and that's exactly the signal the adapters use. Keep them away from outlets shared with big appliances, too.

Checked against TP-Link Support on November 13, 2026.

Good to know

- Speed depends heavily on your wiring. In some homes they work very well; in others, especially with older wiring or outlets on different circuits, they're slow. A pair from a store with an easy return policy lets you find out.
- If the Powerline light stays off or shows red, try an outlet closer to the first adapter.
- Some powerline kits can join TP-Link's OneMesh network as one Wi-Fi name with a compatible router.

CHAPTER 19

MoCA Adapters: Internet over the TV Cable

Many homes have **coaxial cable** jacks (the round, screw-on TV connector) in several rooms, left over from cable TV. **MoCA** adapters (MoCA stands for Multimedia over Coax Alliance) turn that cable into a fast, steady network connection. It's often the best answer for a far bedroom or a basement, because coax is shielded and was built to carry signals.

How it works

- You need **two adapters**, unless your modem or router already has MoCA built in (some provider equipment does).
- One adapter connects to a coax jack and to your router with a network cable.
- The other connects to a coax jack in the far room. Plug in a mesh unit, an access point, a TV or a computer there.
- Current adapters follow the **MoCA 2.5** standard, rated at up to 2.5 Gbps, and work with older MoCA 2.0 and 1.1 equipment. Real speeds are lower than the rating but usually very good.

Checked against Actiontec and TRENDnet product pages on November 13, 2026.

HEADS UP

Satellite TV and some services don't mix

Some MoCA adapter makers warn that their adapters aren't compatible with DirecTV, DISH or other services that use the coax in their own way. If you have satellite TV, check with the adapter maker before buying.

Checked against Actiontec and TRENDnet product pages on November 13, 2026.

GOOD TO KNOW

The little filter at the entry point

Adapter makers recommend a small **MoCA filter** (often called a POE, for point-of-entry, filter) where the cable company's line enters the house, before any splitter. It keeps your MoCA signal inside your home. Old splitters can also block MoCA. This is a good part of the job to have a pro check.

TIP

MoCA plus mesh is a strong pair

A mesh unit connected to a MoCA adapter in the far room gets a wired connection back to the router through the coax. That gives you the speed of wired backhaul without running any new cable.

CHAPTER 20

Which One Fits Your Home?

Use your coverage map (Chapter 8, *Make a Simple Coverage Map*) and this table to narrow it down.

Your situation	Try this first	Then consider
Router is in a corner, closet or on the floor	Move it (Chapter 9, *Move the Router*)	Anything below, if still weak
One weak room, modest home	A plug-in extender, halfway	Provider extender or mesh
Several weak rooms or more than one floor	Mesh Wi-Fi or your provider's extenders	Wired backhaul for the far unit
Coax jacks in the weak rooms	MoCA adapters, with a mesh unit or access point	Powerline
A network jack already in the weak room	A wired access point or mesh unit	No need for wireless repeating
No spare cable of any kind	Mesh Wi-Fi	Powerline adapters
Brick, plaster or stone walls	Mesh with wired or MoCA backhaul	Powerline
A porch, garage or yard camera	See Chapter 23, *Wi-Fi Outdoors*	

FROM BILL

When in doubt, start with the map

A walk test and a quick look at where your cables run usually make the answer obvious. If it doesn't, call me with your map in hand and we'll pick the simplest fix that will actually work.

PART 5

Buying, Outdoors & Staying Safe

Wi-Fi generations in plain English, honest notes on cost, getting Wi-Fi outside, the booster scams, and fixing an extender that misbehaves.

CHAPTER 21

Wi-Fi 6, 6E & 7 in Plain English

Wi-Fi comes in generations, like car model years. The Wi-Fi Alliance, the industry group that certifies equipment, gives each generation a simple number. Here are the ones you'll see on boxes in 2026.

Name on the box	Also called	What it means for you
Wi-Fi 5	802.11ac	Older but still common. Fine for many homes; no longer the one to buy new.
Wi-Fi 6	802.11ax	Handles many devices at once better. Uses the 2.4 and 5 GHz lanes.
Wi-Fi 6E	802.11ax + 6 GHz	Wi-Fi 6 plus a new, less crowded 6 GHz lane. Fast up close, shorter reach.
Wi-Fi 7	802.11be	The newest. Adds wider 320 MHz channels on 6 GHz and **Multi-Link Operation**, letting a device use more than one lane at once for speed and reliability.

Checked against the Wi-Fi Alliance on November 13, 2026.

Do you need the newest?

- **Your devices set the ceiling.** A Wi-Fi 7 extender only delivers Wi-Fi 7 to phones and laptops that support it. Older devices still connect, at their own generation's pace.
- **6 GHz doesn't go far through walls.** The newest lane is great in the same room or the next, less so two floors away. It helps most in mesh systems, where units talk to each other over it.
- **Match the gear.** An extender or mesh unit at least as new as your router makes sense. Buying a Wi-Fi 7 extender for a Wi-Fi 5 router won't make the router newer.

GOOD TO KNOW

Extenders come in Wi-Fi 7 too

Netgear, for example, published a user manual in June 2026 for its Wi-Fi 7 extender models. Newer isn't always necessary; for one weak bedroom and an older router, a Wi-Fi 6 extender is usually plenty.

Checked against Netgear Support on November 13, 2026.

CHAPTER 22

What It Costs

Prices change constantly and vary by store, so here are honest tiers rather than exact numbers. Compare a few stores' current prices before you buy, and favor a store with an easy return policy, since Wi-Fi gear is best judged in your own home.

Option	Cost picture	Notes
Moving the router, restarting, updating	Free	Try these first (Part 3).
A longer cable to move the router	Low	Ethernet or coax cable from a hardware store.
Plug-in extender	Low to moderate	Basic models cost least; three-band and Wi-Fi 7 models cost more.
Powerline adapter pair	Moderate	Pairs with built-in Wi-Fi cost more than wired-only pairs.
MoCA adapter pair	Moderate	Add a small cost for a POE filter if needed.
Mesh system (two or three units)	Moderate to high	Price rises with Wi-Fi generation and the number of units.
Provider's extenders	Monthly fee	Spectrum lists $5.00 a month per Extender (November 2026).
New cable run by a professional	Varies	Get a written quote first.

Checked against Spectrum's WiFi Extenders page on November 13, 2026.

HEADS UP

Mesh subscriptions are optional

Some mesh brands sell optional monthly plans for extra security or parental controls (eero Plus is one). The Wi-Fi works without them. Decide on the subscription separately from the hardware.

TIP

Don't overbuy

A big three-unit system for a small home with one weak bedroom is money spent on capacity you won't use. Start with the smallest fix your map supports; you can usually add a unit later.

CHAPTER 23

Wi-Fi Outdoors

Porches, patios, garages, sheds and yard cameras are some of the hardest places to reach, because exterior walls are usually the thickest in the house: brick, stone, siding with foil-backed insulation, or concrete.

Options from simplest up

1. **Check from a window.** Wi-Fi passes through window glass more easily than through an outside wall. A router, extender or mesh unit near a window that faces the porch may be enough.
2. **Put an indoor extender or mesh unit by the door** nearest the area you want to cover.
3. **Use an outdoor-rated unit** for the yard or a detached building. Several mesh makers sell weatherproof units; check the maker's rating for rain and temperature before mounting one outside.
4. **Reach a detached garage or shed** with a mesh unit in a window, an outdoor unit, or a buried outdoor-rated cable run by a pro.

HEADS UP

Outdoor power and weather

An ordinary indoor extender isn't made for rain, frost or summer heat. Don't plug one into an outdoor outlet or leave it on a porch. Outdoor wiring is a job for an electrician.

TIP

Cameras and doorbells

A video doorbell or yard camera that keeps going offline is often the first sign of weak outdoor Wi-Fi. Check its signal in the camera's app (many show a signal meter), and test again after each change.

CHAPTER 24

Booster Scams & Fake Update Links

Weak Wi-Fi is frustrating, and that makes it a favorite hook for misleading ads and outright scams. Knowing the patterns keeps your money and your accounts safe.

SCAM ALERT

The "miracle booster" ad

Ads and "news-style" articles promise a little plug-in gadget that "internet companies don't want you to know about," claiming it will multiply your speed or get around your plan's limits. A real extender can carry Wi-Fi *farther*; nothing you plug in can make your internet faster than what you pay for. These products are often rebranded and resold under new names after complaints pile up.

SCAM ALERT

The "Wi-Fi upgrade" phone call

A caller says they're from your internet company or "the network department," that your router is outdated or hacked, and that they can fix it now for a fee, or need you to install an app so they can "look at" your network. Hang up. Call your provider back on the number on your bill.

SCAM ALERT

The fake "router update" link

A text, email or pop-up says your router or extender needs an urgent update and gives a link. Real updates happen inside the router's own app or settings page, or automatically. The link leads to a page that steals passwords or installs something nasty.

Shopping safely

- Buy from well-known stores and makers you recognize, with a clear return policy.
- Be wary of reviews that all sound alike and five-star ratings on a brand you've never heard of.
- Ignore a countdown timer or "only 3 left" pressure on a website.
- If the price seems too good for what's promised, it is.

FROM BILL

Ask before you buy

If you've seen an ad for a booster and you're tempted, give me a ring first. I'll tell you honestly whether it's likely to help your home or not.

CHAPTER 25

When an Extender Misbehaves

Extenders are simple, but a few problems come up again and again. Here's what to try.

The extended area is still slow

1. Check the extender's signal light. If it shows weak, move it one outlet closer to the router (Chapter 15, *Placing an Extender*).
2. Make sure it isn't behind furniture, near a microwave, or plugged in at floor level behind something metal.
3. Restart the router and the extender.
4. Check for a firmware update in the maker's app.
5. If it's still poor, the walls may be too much for wireless. Consider wired backhaul, MoCA or powerline (Chapters 17 to 19).

Your phone stays on the wrong network

If your extender makes a second name like **Home_EXT**, a phone may hang on to the router's weak signal instead of switching. Turn Wi-Fi off and on to make it choose again. Some extenders can be set to use the **same name** as the router; with brand-matched systems like TP-Link OneMesh, switching is automatic. A mesh system solves this for good.

It stopped working after a router change

If you changed your Wi-Fi password, got a new router, or the provider swapped equipment, the extender is still looking for the old network. Set it up again from the start (Chapter 14, *Setting Up an Extender*). If it won't let you, its leaflet explains how to reset the extender itself (usually a pin-hole button held for several seconds), which only affects the extender, not your router.

Devices drop off now and then

- Update the device's software and the extender's firmware.
- Keep the extender out of power strips with heavy appliances on them.
- If a smart-home gadget only works on 2.4 GHz, make sure the extender is passing that lane along.

PART 6

When to Call Bill & Your Cheat-Sheet

When a hand saves worry, and every everyday move on a single page.

CHAPTER 26

When to Call Bill

This guide will take you a long way on your own. But part of being helpful is being honest about when a hand saves time, money and frustration. Here's when I'd pick up the phone.

Good reasons to call

- You've tried the free fixes and still have a weak room, and you're not sure what to buy.
- You're setting up a **mesh system** alongside your provider's gateway and want to avoid the "two routers" tangle.
- You'd like **MoCA** set up, including checking the splitters and the entry-point filter.
- A doorbell, camera, medical alert or other important device keeps dropping off Wi-Fi.
- You need Wi-Fi in a garage, shed or yard.
- You've seen a "booster" ad or had a call about your Wi-Fi that doesn't feel right.

Things you can handle yourself

Walk tests, speed tests, moving and restarting the router, setting up and placing a plug-in extender, and pairing powerline adapters. These are all yours now. Keep this guide handy as your refresher.

FROM BILL

How I like to help

I'm Bill, and I bring 30+ years of professional experience to helping folks feel at home with their technology, right here in Portage County, Ohio. I don't rush, I don't talk down to anyone, and I won't sell you more gear than your home needs. I can talk you through it over the phone or a screen share, or come out, walk the house with you and set everything up: $49 remote · $99 in your home. Call **(330) 200-8042** or book at **billshometech.com/book**. If I'm with another client, Sophie, my AI receptionist, will take your details so I can call you back.

Thank you for taking the time to learn this. Good Wi-Fi in every room makes everything else easier, and now you know how to get there.

— Bill

CHAPTER 27

Your Dead-Zone Cheat-Sheet

Keep this handy. The everyday moves, all in one place.

Finding the problem

- **Speed test beside the router, then in the weak room** (speedtest.net or fast.com). Slow everywhere means it's the service, not a dead zone.
- **Walk test:** note your phone's Wi-Fi bars in each room you use.
- **Map it:** sketch rooms, mark the router, write bars and speeds.

Fixing it, cheapest first

Step	What to do
1. Move the router	Central, up high, in the open, antennas up, away from microwaves and metal.
2. Restart and update	Unplug 30 seconds (modem first, then router). Check the app for updates.
3. Check the device	Update it, forget and rejoin, move a streaming stick out from behind the TV.
4. Ask your provider	Current router? Extenders included or rented? (Spectrum: $5.00 a month each.)
5. Add coverage	Extender halfway; mesh for bigger homes; access point, MoCA or powerline for tough walls.

Extender quick rules

- Set it up **near the router**, then move it **halfway** to the weak area.
- Wait about two minutes, then read the signal light. Weak? One outlet closer.
- Powerline adapters go **straight into the wall**, never a power strip or surge protector.

The safety rules

- No plug-in gadget makes your internet faster than your plan.
- Never let a caller "fix" your Wi-Fi or install an app.
- Update routers and extenders only from their own app or settings page.
- When something feels off, stop and ask.

My Wi-Fi notes	
My router is in	_____

My Wi-Fi notes	
My weak rooms	_____
Extender or mesh brand	_____
Internet company and phone	_____
Bill's Home Tech	(330) 200-8042 · billshometech.com/book

WHAT THIS DOES FOR YOU

Wi-Fi where you actually live

You know why the Wi-Fi fades, how to find the weak spots, which free fixes to try, and how to choose the right help when you need it. That means steady video calls, smooth streaming and cameras that stay online, in every room that matters. Well done.

Bill's Home Tech · Complete Manuals Series · (330) 200-8042 · billshometech.com · Portage County, Ohio