BILL'S HOME TECH

Home & Small Business Tech Solutions

AN EXTENDED GUIDE · NO. 2144

Updated November 2026

Fire TV Stick Frozen or Stuck on the Logo

When your Fire TV Stick freezes mid-show or hangs on the Amazon logo — the calm way to revive it

Plain-English TV help from:
Bill's Home Tech
Portage County, Ohio

Tech Made Simple. Service Made Personal.

Bill Davis — Bill's Home Tech
(330) 200-8042 · bill@billshometech.com · Atwater, Ohio

Book a visit · billshometech.com/book

What's Inside

Everything in this guide, with page numbers. Skip to whichever chapter answers your question right now.

The 60-Second Version 3
The Short Version 3
Why a Fire TV Stick Freezes 4
The Remote Restart — Try This First 4
The Menu Restart 5
If It Won't Get Past the Amazon Logo 6
The Full Power Cycle 7
Fix the Power Supply 7
Let It Cool and Breathe 8
Clear a Troublesome App 8
Update the Software 9
Is It the Stick, the TV, or the Internet? 9
The Last Resort: Factory Reset 10
Keep It From Freezing Again 10
When to Call Bill 11
Everyday Cheat Sheet 12
A Note From Bill 13
Your Visit — and My Promise 14

SUMMARY

The 60-Second Version

A Fire TV Stick that freezes or hangs on the Amazon logo is almost always jammed or short on power, not broken. First try the remote restart — hold Select and Play/Pause together for about ten seconds. If it stays frozen, unplug the stick's power for a full minute and reseat it.

The biggest cause of repeated freezing is running it from a TV USB port, so use the included wall adapter, and use the HDMI extender so it does not overheat behind the TV. A factory reset is a last resort because it erases every app and sign-in.

1 The Short Version

A Fire TV Stick that freezes or hangs on the Amazon logo is almost always suffering a temporary jam or not getting enough steady power. Both are fixable at home in a few minutes, and nothing here erases your apps or logins unless you deliberately choose the last-resort factory reset.

Work down these steps in order and stop as soon as it comes back to life. Most sticks are fine again by the second or third step.

- A frozen Fire TV Stick is rarely broken — it is jammed or short on power.
- The quickest revival is the remote restart: hold Select and Play/Pause together.
- If that fails, unplug the stick's power for a full minute and plug it back in.
- Power it from the included adapter in a wall outlet, not a TV's USB port.

> *A stick stuck on the Amazon logo looks dead, but it is almost always just jammed — and a proper restart wakes it right up.*

2 Why a Fire TV Stick Freezes

A Fire TV Stick is a tiny computer, and like any computer it can occasionally get its wires crossed and lock up, especially when it is low on memory or an app has misbehaved. A good restart clears that jam completely. This is by far the most common cause of a frozen stick, and the easiest to fix.

The other frequent culprit is power. A Fire TV Stick run from a TV's USB port instead of its own wall adapter may not get quite enough electricity, which can cause freezing, restarting, and hanging on the logo. Heat plays a part too — a stick crammed in a tight space behind the TV can get too hot and seize up. Knowing these causes points you straight at the fixes that work.

> **GOOD TO KNOW**
>
> None of this means your stick is failing. A frozen screen feels dramatic, but a jam, a weak power source, and a little too much heat are all easy to put right — and the stick is usually perfectly healthy once they are sorted.

3 The Remote Restart — Try This First

If the remote still responds at all, the fastest way to revive a frozen Fire TV Stick is a restart triggered right from the remote, with no need to reach behind the TV.

1. Press and hold the Select button (the center of the ring) and the Play/Pause button at the same time.
2. Keep holding both for about ten seconds, until the screen goes dark or shows a restarting message.
3. Let go and wait — the stick will restart on its own and return to the home screen in a minute or two.
4. If nothing happens after a couple of tries, the stick is fully jammed; move on to the power cycle.

WATCH OUT

Do not confuse this with holding Back and the Right-arrow together — that combination starts a factory reset, which erases everything. The restart you want is Select plus Play/Pause. If you ever see a reset countdown by mistake, press any other button to cancel it.

4 The Menu Restart

If the screen is responsive enough to reach the menu, a restart from Settings is a clean, gentle option that clears most temporary trouble.

1. From the home screen, go to Settings (the gear), then My Fire TV (or Device & Software).
2. Choose Restart and confirm.
3. Let the stick shut down and start up fully before touching the remote again.

TIP

A gentle menu restart once a week or two keeps a Fire TV Stick snappy and heads off the freezes before they start — the same way a quick restart keeps a phone or computer healthy.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

5 If It Won't Get Past the Amazon Logo

A stick that lights up but hangs on the glowing Amazon logo, never reaching the home screen, is the single most common Fire TV complaint. It almost always comes down to the same two causes we keep returning to — power and a jammed start-up — so the fixes are the ones already in this guide, applied patiently and in order.

The first thing to understand is that the logo screen can genuinely take a few minutes after an update or a long time unplugged, so a little patience comes first. If it truly will not move past the logo after several minutes, the stick is stuck part-way through starting up, and it needs a firm, complete power cycle rather than a gentle nudge.

1. Give it a full five minutes on the logo before deciding it is stuck — start-up can be slow.
2. Unplug the stick's power for a full minute, reseat the stick in the HDMI port, and plug it back in.
3. Switch to the included wall adapter if you have been using a TV USB port — this alone fixes many logo hangs.
4. If it reaches the logo and restarts over and over, that loop is a power problem until proven otherwise.
5. Only if patient power cycling with a good adapter fails should you consider the factory reset later in this guide.

> **GOOD TO KNOW**
>
> A stick that loops on the logo — logo, black, logo again — is behaving exactly like a device that keeps running out of power at the worst moment. That is why the wall adapter so often ends it: the stick finally has enough steady electricity to finish starting up.

6 The Full Power Cycle

If the stick is frozen solid and the remote restart will not take, pulling the power revives it almost every time. This empties its short-term memory for a clean start and is perfectly safe — your apps and sign-ins are untouched.

1. Unplug the stick's power cable from the wall or adapter — do not just turn off the TV.
2. Leave it unplugged for a full minute so it powers down completely.
3. Pull the stick out of the HDMI port and firmly reseat it while you are there.
4. Plug the power back in and let it start up fully before pressing anything.

WATCH OUT

Turning off the TV is not the same as cutting the stick's power, especially if the stick runs from its own wall adapter. Unplug the stick's own power cable to be sure it truly restarts.

7 Fix the Power Supply

Because weak power causes so much freezing, it is worth making sure the stick is powered the way Amazon intended. This one change cures a great many stubborn cases.

- Use the power adapter and cable that came with the stick, plugged into a wall outlet.
- Avoid running the stick from a TV USB port — it often cannot supply steady power.
- If the cable is frayed or a mismatched replacement, swap in a proper Amazon power kit.
- Make sure the adapter is in a working outlet, not a switched one that gets cut off.

GOOD TO KNOW

You can buy an official Fire TV power adapter inexpensively if yours was lost or you have been using the TV's USB port. If you are not sure which one your model needs, that is an easy thing for me to bring and confirm on a visit.

8 Let It Cool and Breathe

If the stick is hot to the touch or wedged into a cramped space behind the TV, heat may be causing the freeze. A stick that overheats will lock up until it cools.

1. Unplug the stick and let it rest and cool for ten to fifteen minutes.
2. Use the short HDMI extender cable that came with it so the stick hangs in open air.
3. Keep it out of closed cabinets, off warm devices, and out of direct sun.
4. Plug it back in and see whether the freezing stops now that it can breathe.

TIP

That little HDMI extender in the box is not optional packaging — it exists to keep the stick cool and to lift it out of the metal shadow of the TV, which also improves its Wi-Fi. If yours has been lost, an inexpensive replacement is well worth it.

9 Clear a Troublesome App

If the stick itself is fine but one app keeps freezing, give that app a fresh copy rather than resetting the whole stick.

1. Go to Settings, then Applications, then Manage Installed Applications.
2. Choose the troublesome app and select Clear cache, then try it again.
3. If it still misbehaves, choose Uninstall, then reinstall it from the app store and sign in.
4. Opening a freshly installed app usually behaves, now that the clutter is gone.

WATCH OUT

Uninstalling an app means signing back in afterward, so have that service's email and password ready first. If you do not know the login, clear the cache only — or let me help recover it — rather than uninstalling.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

10 Update the Software

Once the stick is responsive, make sure its software is current, since an out-of-date Fire TV Stick can be glitchy and prone to freezing.

1. Go to Settings, then My Fire TV, then About, then Check for Updates.
2. Install anything it finds and let it restart to finish — a single clean restart is normal.
3. Give it a few minutes; a large update can take a little while to settle.

GOOD TO KNOW

A stick that has fallen well behind on updates sometimes cannot steady itself until it is nursed through one good update. If it stays on long enough to reach this menu, getting it current can be what finally stops the freezing.

11 Is It the Stick, the TV, or the Internet?

Before you do anything drastic, a moment's checking confirms the stick is really the problem, so you fix the right thing.

- If the TV shows its own menu and other inputs fine, the TV is healthy — look at the stick.

- If the stick loads but apps will not play, suspect the Wi-Fi or internet, not the stick.
- If the stick is dead on every port and TV you try, the stick or its power is at fault.
- If only one app freezes, it is that app, not the stick.

1. Switch the TV to another input to confirm the screen works.
2. Move the stick to a different HDMI port, or another TV, to test it alone.
3. Open a different app — if everything fails to play, check your internet.

12 The Last Resort: Factory Reset

If nothing else works, a factory reset returns the stick to how it came from the box. This is a genuine last resort — it erases every app and sign-in, so you will set it up from scratch afterward and re-enter your Wi-Fi and all your streaming logins.

Only do this once power, heat, and updates have all been ruled out, and only if you are comfortable signing back into everything. If you are at all unsure, pause here rather than risk locking yourself out of your own apps.

> **WATCH OUT**
> A factory reset is the point where I would rather you call me. It is not dangerous, but re-entering every streaming login afterward is tedious, and a missing password can turn a small problem into a long afternoon. I can run the reset and leave you signed back into everything before I go.

13 Keep It From Freezing Again

Once the stick is behaving, a few small habits keep it that way. Most of them protect the three things a Fire TV Stick needs: steady power, a little air, and current software.

- Keep it on the included wall adapter rather than a TV USB port.
- Leave the HDMI extender in place so the stick stays cool and out of the TV's shadow.
- Let it install updates — leaving it on overnight now and then keeps it current.

- Give it a gentle menu restart every week or two, long before it starts to freeze.
- Remove apps you never use, so the stick's small memory is not needlessly crowded.

> *Steady power, a little air, and current software — give a Fire TV Stick those three and the freezes rarely return.*

GOOD TO KNOW

A Fire TV Stick has only a modest amount of memory, so a screen stuffed with apps you never open leaves less room for the ones you do. A quick spring-clean of unused apps often makes the whole stick feel faster and steadier.

14 When to Call Bill

Most frozen Fire TV Sticks come straight back with a restart and the right power supply, and this guide gets most people there. But if yours keeps freezing no matter what, or you have reached the factory-reset step and would rather not risk your sign-ins, there is no need to struggle with it.

I come to you, work out whether it is power, heat, software, or the stick itself, and set it right — bringing the correct power kit or an HDMI extender if that is what it needs. If a reset is called for, I handle it and sign you back into all your apps, so you are left watching, not wrestling.

- It keeps freezing even after a power cycle and using the proper wall adapter.
- The stick runs hot and locks up, and you need it moved into open air.
- You have reached the factory-reset step and want your logins kept safe.
- You are not sure which power adapter or extender your stick needs.

CHEAT SHEET

Everyday Cheat Sheet

Keep this by the TV. Try these in order; most freezes clear by the power cycle.

I want to...	Do this...
Revive it fast	Hold Select + Play/Pause together for about 10 seconds to restart
Restart from the menu	Settings My Fire TV Restart
Unfreeze a dead stick	Unplug its power for a full minute, reseat the stick, plug back in
End repeated freezing	Power it from the included wall adapter, not a TV USB port
Stop overheating	Use the HDMI extender so the stick hangs in open air
Fix one bad app	Settings Applications Manage Clear cache, or reinstall it
Get help	Call Bill: (330) 200-8042

BEFORE YOU GO

A Note From Bill

A quick note from Bill. I write these guides to make home tech a little less frustrating, and I do my best to keep every step accurate and up to date. Still, every home, device, and setup is a bit different, so I can't promise a guide will match yours exactly or fix your particular problem. These guides are for general information only — they're not professional, legal, or financial advice, and they don't replace your device's own manual or the manufacturer's instructions. Please go slow, use your own good judgment, and use everything here at your own risk. If a step involves electrical wiring, a gas appliance, a water heater, plumbing, or climbing a ladder — or if anything just doesn't feel safe — please stop and call a licensed professional (or give me a call at 330-200-8042). Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results.

HOW I CAN HELP

Your Visit — and My Promise

You don't have to remember all of it — just that a friendly, patient person is one call away, whenever you'd rather have a hand.

KEY SPECS

In your home — $99 flat for the first visit, no contracts and no surprises, with a 30-day come-back-free follow-up. In-home visits cover Portage County, Ohio and nearby communities.
Outside the area? Remotely — $49 for a screen-share session (free for Support Plan members, $39/mo), refundable if I can't fix it — and credited toward a visit if you'd rather have me in person. Book either at billshometech.com/book.

GOOD TO KNOW

My promise — If you're not 100% satisfied with your visit, I'll come back at no charge, or refund the full $99. No questions, no awkwardness. That's how I'd want to be treated.

Whenever you're ready, I'll come to your home anywhere in Portage County, Ohio and nearby communities, at your pace. Too far for a house call? I also help remotely. Book at billshometech.com/book or call (330) 200-8042. — Bill

Call or text (330) 200-8042 · bill@billshometech.com

This free guide is for general information only — not professional advice, and no substitute for your device's own manual. Any prices or outside products mentioned can change; please confirm current details before you buy. Please use your own good judgment and follow it at your own risk — for anything involving electricity, gas, water, or heights, stop and call a licensed professional. Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results. © 2026 Bill's Home Tech, LLC.