BILL'S HOME TECH

Home & Small Business Tech Solutions

AN EXTENDED GUIDE · NO. 2113

Updated November 2026

The App Closed Itself and Won't Reopen

An app vanished mid-use or won't open at all — here's the calm ladder back to working

Plain-English tech help from:
Bill's Home Tech
Portage County, Ohio

Tech Made Simple. Service Made Personal.

Bill Davis — Bill's Home Tech
(330) 200-8042 · bill@billshometech.com · Atwater, Ohio

Book a visit · billshometech.com/book

What's Inside

Everything in this guide, with page numbers. Skip to whichever chapter answers your question right now.

The 60-Second Version 3

The Short Version 3

Why Apps Crash (It's Not Your Fault) 4

Step 1: Fully Close the App and Reopen 4

Step 2: Restart the Device 5

Step 3: Check Your Storage Space 5

Step 4: Update the App 6

Step 5: Check Whether It Needs the Internet 7

Step 6: Clear the App's Temporary Files 7

Step 7: Delete and Reinstall the App 8

Is the App's Service Down? 8

One App or Every App? 9

Prevent Apps From Crashing 10

Games and Other Heavy Apps 10

A Brand-New or Just-Installed App 11

When to Call Bill 11

Everyday Cheat Sheet 13

A Note From Bill 14

Your Visit — and My Promise 15

SUMMARY

The 60-Second Version

When an app closes itself or won't reopen, it has stumbled — usually from low storage, needing an update, or a momentary glitch — and your information is almost always safe. Climb a short ladder: reopen it, then fully close it by swiping it away in the recent-apps list and reopening, then restart the device.

The biggest lasting cause is low storage space, so free some up. Update the app in the official store, since makers fix crash bugs there. As a last resort, delete and reinstall it and sign back in.

If many apps crash together, the device (not the apps) is the issue — free space and restart. And if lots of people's version of a popular app fails at once, it's the company's outage, so just wait.

1 The Short Version

When an app closes itself or won't reopen, it has simply stumbled — usually because it ran low on room to work, needs an update, or hit a momentary glitch. It's not a sign your device is failing, and it's rarely your fault in any way.

The fixes form a short ladder from gentlest to firmest: reopen it, fully close and reopen it, restart the device, free up space, update the app, and as a last resort reinstall it. Most crashes clear within the first few rungs, and your information stays safe throughout.

- An app crashing or not opening is ordinary — rarely a sign of real trouble.
- Climb the ladder: reopen, fully close, restart, free space, update, reinstall.
- Low storage space is the single most common cause of repeated crashing.
- Your photos, messages, and data in the app are almost always safe.

TIP

Before anything involved, just try opening the app again — give it a few seconds to load fully. A one-off crash often doesn't repeat, and a moment's patience on the second try saves you the rest of the ladder more often than you'd expect.

2 Why Apps Crash (It's Not Your Fault)

Apps are complicated pieces of software, and now and then one trips over itself — runs out of room, hits a bug, or gets confused by a bad connection. When it does, the device protectively closes it rather than letting it misbehave, which is why it 'vanishes.'

- Low storage space: the app has no room to work and gives up.
- An out-of-date app that needs the latest version to run smoothly.
- A momentary glitch or a poor internet connection mid-task.
- Too many apps open at once, crowding the device's working memory.
- A bug the app's makers haven't fixed yet, which an update usually cures.

GOOD TO KNOW

The device closing a misbehaving app is actually a feature, not a failure — it's protecting the rest of your device from one app's bad moment. That's why a crash feels abrupt but leaves everything else working fine.

3 Step 1: Fully Close the App and Reopen

If simply tapping it again didn't help, the next step is to fully close the app — not just leave it — and open it fresh. A crashed app sometimes lingers in a confused state, and clearing it out lets it start clean.

1. Open the list of recent apps: on most phones, swipe up from the bottom and pause, or double-press the Home button.

2. Find the troublesome app in the list and swipe it away (usually up or to the side) to fully close it.
3. Return to the home screen and tap the app to open it fresh.
4. Give it a few seconds to load completely.

> **TIP**
> Swiping an app away to close it fully is different from just leaving it, and it clears a crashed app's confusion without touching your information. It's safe to do anytime and fixes a great many 'it won't open right' moments.

4 Step 2: Restart the Device

If closing and reopening the app didn't do it, a full restart of the device clears the slate for everything, including whatever tangled up the app. It's the reliable next rung.

1. Restart the phone, tablet, or computer the normal way (hold the power button, choose Restart or Power Off, then back on).
2. Let it start up completely before trying the app again.
3. Open the app and see if it behaves now.
4. If the device itself seemed frozen, a force restart may be needed first.

> **GOOD TO KNOW**
> A restart clears the device's short-term working memory, which is often exactly what a crash-prone app needs. If several apps have been misbehaving, a restart frequently sets all of them right at once.

5 Step 3: Check Your Storage Space

Here's the big one. A device nearly out of storage space causes apps to crash constantly, because they have no room to do their work. Freeing some space is often the real, lasting cure for an app that keeps closing.

1. Open Settings and find the storage information (often under General or Device Care).
2. See how much free space is left; if it's nearly full, that's very likely your cause.
3. Delete apps you don't use, clear old downloads, and let photos back up so you can remove local copies.
4. Empty the trash or recycle bin, which often holds more than you'd think.
5. Aim to free up a comfortable cushion, then try the app again.

WATCH OUT

If your device has been warning that storage is full, don't ignore it — a full device doesn't just crash apps, it can refuse updates and slow to a crawl. Freeing space is one of the most valuable bits of housekeeping there is, and it fixes a whole family of problems.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

6 Step 4: Update the App

An out-of-date app is a very common reason for crashing, because the makers release updates specifically to fix the bugs that cause it. Updating often ends the crashing outright.

1. Open the official app store (App Store or Play Store).
2. Find the updates area and look for the troublesome app.
3. Update it (and, while you're there, your other waiting updates).
4. Open the app fresh once it's updated.

> **GOOD TO KNOW**
> If an app started crashing recently with no other explanation, a waiting update is the most likely fix — the makers have probably already addressed it. Turning on automatic app updates means future bug-fixes arrive without you having to remember.

7 Step 5: Check Whether It Needs the Internet

Some apps can't open properly, or close in frustration, when they can't reach the internet. If an app won't start, it's worth confirming your connection is healthy.

1. Check that other apps and websites are loading, to confirm your internet works.
2. If your connection is down, fix that first — the app may open fine once you're back online.
3. Try switching between Wi-Fi and cellular data to see if one works better.
4. Give the app another try once the connection is solid.

> **GOOD TO KNOW**
> An app that depends on the internet can behave strangely — opening to a blank screen, hanging, or closing — when the connection is poor. It's not the app failing so much as waiting; a steady connection usually settles it.

8 Step 6: Clear the App's Temporary Files

Apps build up temporary files as they run, and occasionally that store gets corrupted and makes the app crash. Clearing it is safe and often revives a stubbornly crashing app, especially on Android.

1. On Android: open Settings, go to Apps, pick the app, choose Storage, and tap 'Clear cache' (not 'Clear data,' which removes more).
2. On an iPhone: there's no cache button, but 'offloading' the app in Settings (under the app's storage) removes it while keeping your data, then you reinstall it fresh.

3. Open the app again afterward and check it runs.
4. You may need to sign in again, which is normal.

> **WATCH OUT**
> On Android, choose 'Clear cache,' not 'Clear data' or 'Clear storage' — the first just tidies temporary files, while the others can wipe the app's saved information and sign-ins. When unsure which you're tapping, stop and check, or let someone experienced do it.

9 Step 7: Delete and Reinstall the App

As a last resort for one stubborn app, removing it and installing it fresh clears out whatever got tangled. For most apps your information lives in your account online, so reinstalling brings it all back when you sign in.

1. Press and hold the app's icon and choose to delete or uninstall it.
2. Go to the official app store and install it again fresh.
3. Open it and sign in with your account.
4. Check that your information is there (it usually syncs back from your account).

> **WATCH OUT**
> Before deleting an app, make sure anything stored only inside it — not in an online account — is saved elsewhere first. Most apps keep your data in your account, so reinstalling is safe, but a few store things locally. If you're unsure, check before uninstalling.

10 Is the App's Service Down?

Sometimes the app isn't the problem at all — the company behind it is having an outage, and every user's app is misbehaving at once. Checking spares you from reinstalling something that was never broken.

1. Check whether other apps work fine; if only this one fails, suspect its service.

2. Search the app's name plus 'down' or 'status' to see if others are reporting problems.
3. If it's a widespread outage, there's nothing to fix — just wait and try later.
4. Avoid reinstalling or changing settings during an outage, which only adds confusion.

GOOD TO KNOW

If a popular app suddenly crashes for you and lots of other people at the same time, it's the company's servers, not your device. The outage guides show how to confirm it — and the fix is simply patience.

Rather not do this yourself? I'll come to your home and set it up for you — a flat $99 first visit across Portage County, Ohio and nearby communities. Outside the area? I also help remotely by phone or screen-share. Book at billshometech.com/book or call (330) 200-8042.

11 One App or Every App?

Noticing whether it's one app or many points you to the right cause. They're quite different problems with different cures.

- Just one app crashing: that app needs updating, clearing, or reinstalling — the steps above.
- Many apps crashing: the device itself is the issue, usually low storage or needing a restart.
- All apps slow and crashing together: free up space and restart, which often cures the lot.
- A brand-new device crashing often: worth having checked, as that's unusual.

WATCH OUT

If several apps are all crashing, don't bother reinstalling each one — the problem is the device, not the apps. Freeing storage space and restarting is the fix that addresses all of them at once.

12 Prevent Apps From Crashing

A few gentle habits keep apps running smoothly and crashes rare. None take any real effort.

- Keep a comfortable cushion of free storage space — this prevents the most crashes.
- Let apps update, ideally automatically, so bug-fixes arrive promptly.
- Restart your device about once a week to clear the clutter.
- Close heavy apps when you're done rather than leaving many open at once.

> **GOOD TO KNOW**
>
> Storage space and updates are the two levers that prevent most app crashes. A device with room to breathe and up-to-date apps simply crashes far less — it's worth a little housekeeping to stay there.

13 Games and Other Heavy Apps

Some apps ask much more of a device than others — games, video apps, photo editors, and map apps are the heavyweights, and they're the first to crash when a device is short of room or power. Knowing this explains why your demanding apps stumble while simple ones don't.

- Heavy apps need lots of free storage and working memory — crowd them and they crash.
- Close other apps before opening a demanding one, to give it room.
- Keep heavy apps especially up to date, as they get frequent bug-fixes.
- An older device may simply struggle with the newest, heaviest apps — that's wear, not breakage.

GOOD TO KNOW

If only your most demanding apps crash while everyday ones run fine, your device is near its limits for those apps. Freeing space and closing others before you open a heavyweight usually steadies it; on a very old device, the heaviest apps may always be a stretch.

14 A Brand-New or Just-Installed App

When an app you just installed won't open, the causes are slightly different — the install may be incomplete, or the app may not suit your device. A few checks sort it out.

1. Make sure the install actually finished; a poor connection can leave it half-installed, so delete and reinstall it on good Wi-Fi.
2. Check the app is meant for your device and its version — the app store usually warns if not.
3. Restart the device after installing, which lets a new app settle in.
4. Confirm you have enough free space for it to run, not just to install.

TIP

A newly installed app that won't open is most often a half-finished download — reinstalling it on a solid Wi-Fi connection fixes the majority. If the store warned it wasn't compatible with your device, though, that's the honest reason, and no reinstalling will change it.

15 When to Call Bill

You can safely climb this whole ladder, and most crashing apps are revived by a restart, some free space, or an update. But if one important app keeps crashing no matter what, if every app is unstable, or if you're nervous about clearing or reinstalling something and losing information, there's no need to risk it alone.

I come to you, find why an app keeps crashing — usually a full storage drive or an app needing a proper reinstall — and fix it without putting your information at risk. I'll also set your device up with the space and automatic updates that keep crashes away for good.

- One important app keeps crashing despite updating and reinstalling.
- Many apps are unstable, which points to the device itself.
- You're worried about losing information if you clear or reinstall an app.
- You'd like your device set up to stop apps crashing in the first place.

CHEAT SHEET

Everyday Cheat Sheet

App crashed or won't open? Climb this ladder — your information stays safe throughout.

I want to...	Do this...
Try the gentlest fix	Reopen it; give it a few seconds to load fully
Clear a crash	Fully close it (swipe it away in recent apps), then reopen
Reset the whole device	Restart the phone, tablet, or computer
Fix repeat crashing	Free up storage space — the number-one cause
Fix a buggy app	Update it in the official app store
Last resort	Delete and reinstall it, then sign back in
Get help	Call Bill: (330) 200-8042

BEFORE YOU GO

A Note From Bill

A quick note from Bill. I write these guides to make home tech a little less frustrating, and I do my best to keep every step accurate and up to date. Still, every home, device, and setup is a bit different, so I can't promise a guide will match yours exactly or fix your particular problem. These guides are for general information only — they're not professional, legal, or financial advice, and they don't replace your device's own manual or the manufacturer's instructions. Please go slow, use your own good judgment, and use everything here at your own risk. If a step involves electrical wiring, a gas appliance, a water heater, plumbing, or climbing a ladder — or if anything just doesn't feel safe — please stop and call a licensed professional (or give me a call at 330-200-8042). Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results.

HOW I CAN HELP

Your Visit — and My Promise

You don't have to remember all of it — just that a friendly, patient person is one call away, whenever you'd rather have a hand.

KEY SPECS

In your home — $99 flat for the first visit, no contracts and no surprises, with a 30-day come-back-free follow-up. In-home visits cover Portage County, Ohio and nearby communities.
Outside the area? Remotely — $49 for a screen-share session (free for Support Plan members, $39/mo), refundable if I can't fix it — and credited toward a visit if you'd rather have me in person. Book either at billshometech.com/book.

GOOD TO KNOW

My promise — If you're not 100% satisfied with your visit, I'll come back at no charge, or refund the full $99. No questions, no awkwardness. That's how I'd want to be treated.

Whenever you're ready, I'll come to your home anywhere in Portage County, Ohio and nearby communities, at your pace. Too far for a house call? I also help remotely. Book at billshometech.com/book or call (330) 200-8042. — Bill

Call or text (330) 200-8042 · bill@billshometech.com

This free guide is for general information only — not professional advice, and no substitute for your device's own manual. Any prices or outside products mentioned can change; please confirm current details before you buy. Please use your own good judgment and follow it at your own risk — for anything involving electricity, gas, water, or heights, stop and call a licensed professional. Bill's Home Tech and Bill Davis can't be responsible for any damage, data loss, or injury that results. © 2026 Bill's Home Tech, LLC.